



MR320 Series ZapFREE® Fiber Optic Incremental Encoder System and ZAPPY® Software Technical Manual

Doc No: 98-0320-08
Rev: C 10/5/2015



MICRONOR INC.
900 Calle Plano, Suite K
Camarillo, CA 93012 USA
Tel +1-805-389-6600
Fax +1-805-389-6605
sales@micronor.com
www.micronor.com

For support in Europe:

MICRONOR AG.
Pumpwerkstrasse 32
CH-8105 Regensdorf
Switzerland
Tel +41-44-843-4020
Fax +41-44-843-4039
sales@micronor.ch
www.micronor.ch

Notice of Proprietary Rights

The design concepts and engineering details embodied in this manual, which are the property of MICRONOR INC., are to be maintained in strict confidence; no element or detail of this manual is to be spuriouly used, nor disclosed, without the express written permission of MICRONOR INC. All rights are reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission from MICRONOR INC.

© COPYRIGHT 2004-2015, MICRONOR INC.
CAMARILLO, CALIFORNIA
UNITED STATES OF AMERICA

Revision History

Revision	Date	Notes
A	7/10/2012	<ul style="list-style-type: none">• Includes updated MR320 Controller with embedded USB• Includes new MR324 Pocket Hole Sensor (IP65)
B	4/22/2013	<ul style="list-style-type: none">• Includes new MR324 Pocket Hole Mode• Includes new MR325 Sensor
C	10/5/2015	Update with new Camarillo address

Table of Contents

1. PRODUCT DESCRIPTION	6
2. WARRANTY INFORMATION	7
2.1 LIMITATIONS OF WARRANTY	7
2.2 CONTACT INFORMATION	7
3. SPECIFICATIONS	8
3.1 MR320 CONTROLLER	8
3.2 MR322 SIZE 58MM SENSOR	10
3.3 MR324 HIGH RESOLUTION HOLLOW SHAFT SENSOR	11
3.4 MR325 SIZE 125MM HIGH RESOLUTION SENSOR	12
3.5 MR326 SIZE 90MM HEAVY DUTY SENSOR	13
3.6 MR328 SIZE 58MM MRI-COMPATIBLE SENSOR	15
4. INITIAL PREPARATION	16
4.1 STANDARD CONTENTS	16
4.2 UNPACKING AND INSPECTION	16
4.3 DAMAGE IN SHIPMENT	16
5. INSTALLATION GUIDELINES	17
5.1 SYSTEM PLANNING	17
5.2 MOUNTING THE SOLID SHAFT ENCODER SENSORS	18
5.2.1 Face Mount to Counter-Bored Panel	19
5.2.2 Thru-Hole Panel Mount with Hold-Down (Synchro) Clamps	21
5.3 MOUNTING THE HOLLOW-SHAFT ROTARY ENCODER	22
5.4 MOUNTING THE CONTROLLER MODULE	24
5.5 MAKING OPTICAL CONNECTION TO THE CONTROLLER MODULE	24
5.6 MAKING ELECTRICAL CONNECTIONS TO THE CONTROLLER MODULE	25
5.7 FIBER OPTIC CABLE, CONNECTIONS AND ROUTING	29
5.8 FIRST TIME START-UP	30
5.9 MANUAL GAIN CALIBRATION (MANUAL RESET)	31
5.10 ZAPPY™ INSTALLATION AND SETUP SOFTWARE	31
5.11 INITIAL PERFORMANCE VERIFICATION WITH ZAPPY™	33
6. OPERATION AND DESCRIPTION OF FUNCTIONS	39
6.1 BLOCK DIAGRAM	41
6.2 FIRMWARE FUNCTIONS AND PROGRAMMING	44
6.2.1 Serial Communications Interface Specification	44
6.2.2 Communications Protocol	44
6.2.3 The Block Check Character <BCC>	46
6.3 CONFIGURATION COMMANDS AND PARAMETERS	47
6.3.1 Configuration Commands (Registers 10-19)	48
6.3.2 User Commands (Registers 20-2A)	49
6.3.3 Diagnostic Commands (Registers 30-39)	51
6.4 COMMUNICATIONS/PROGRAMMING EXAMPLE	52
6.5 DETAILED DESCRIPTION OF EACH FUNCTION	53
6.5.1 Counter (Register 20)	53
6.5.2 Divider (Register 21)	53
6.5.3 RPM (Register 22)	54

6.5.4	Voltage Mode (Register 23).....	54
6.5.5	Voltage Scale (Register 24).....	56
6.5.6	Voltage Filter (Register 25).....	57
6.5.7	Current Mode (Register 26).....	58
6.5.8	Current Scale (Register 27).....	62
6.5.9	Current Filter (Register 28).....	62
6.5.10	Counter Reset (Register 29)	63
6.5.11	Counter Multiplier (Register 2A)	64
6.5.12	Encoder Direction (Register 2B)	64
6.5.13	Hardware Reset Value (Register 2C).....	65
6.5.14	Reset On Count/Homing (Register 2D).....	66
6.5.15	Saving Parameters in EEPROM (Register 13)	67
7.	MAINTENANCE AND SERVICE.....	68
7.1	ENCODER WILL NOT PRODUCE QUADRATURE SIGNALS.....	68
7.1.1	LED's Do Light Up	68
7.1.2	LED's Do NOT Light Up	68
7.2	INTERFACE PROBLEMS	69
7.2.1	Testing The USB Interface.....	69
7.2.2	Testing The Serial Cable.....	69
7.3	FIBER OPTIC CONNECTOR CLEANING	70
7.3.1	WET Cleaning Method.....	71
7.3.2	DRY Cleaning Method - Micronor MR321C DRY Cleaning Kit.....	71
7.4	TROUBLESHOOTING.....	72
7.5	HOW TO VERIFY VISUAL CONTINUITY OF FIBER OPTIC CABLE LINK	72
7.6	BLINKING ERROR CODES	74
8.	REFERENCE DRAWINGS.....	75


List of Figures

Figure 1. Shafted Encoder Face Mount via Counter-Bored Panel	20
Figure 2. Shafted Encoder Mounting via Thru-Hole With Synchro Clamps.....	21
Figure 3. Hollow Shaft Encoder Mounting Options.	23
Figure 4. Mounting MR320 Controller on DIN Rail.	24
Figure 5. Making Duplex LC Optical Connection to MR320 Controller.....	25
Figure 7. How To Insert and Remove Wires From the WAGO Plug.....	26
Figure 8. Inserting/Removing the WAGO Plug From The MR320 Controller Module.	26
Figure 10. Typical MR320 Series Fiber Optic System connections using Sensor with Duplex LC Pigtail	29
Figure 11. Typical MR320 series system using Harsh Environment ODVA LC Duplex (IP-LC) Connections	29
Figure 12. How to Manually Reset the Controller Module With WAGO Tool.....	31
Figure 15. Initial OPERATE Screen if encoder is inactive.	35
Figure 16. OPERATE Screen displays Real-time Encoder Operation.	35
Figure 19. INSTRUCTIONS Screen View offers Online Instructions and Reference Information.	38
Figure 20. Block Diagram of the MR320 Series Fiber Optic Encoder System.	42
Figure 21. Set-up Parameters for HYPERTERMINAL Program.	70
Figure 22. Dirty and Clean Fiber Optic Connector Ferrule and Endface Views.....	71
Figure 23. WET Cleaning Method Requires IPA & Dry Wipes OR Pre-Wetted Wipes & Dry Wipes.....	71
Figure 24. How To Use the MR321C Kit For Cleaning Duplex LC Optical Connectors and Interfaces.	72
Figure 25. How To Verify Optical Continuity With A Visual Fault Locator.....	73

1. Product Description

The MR320 Series ZapFree® Fiber Optic Incremental Rotary Encoders () are the ideal EMI-immune sensor solution for use in all types of harsh environments and hazardous locations. The MR320 series is the second generation of Micronor's fiber optic encoders - originally released as the MR310 series in 2004 and awarded U.S. Patent 7,196,320.

The Micronor fiber optic encoder system is comprised of a passive Sensor linked via a duplex fiber optic link to the remote Controller Module. The motion control designer can count on these features:



- 100% passive optical sensor
- Immune to electromagnetic interference (EMI)
- No electromagnetic emissions
- No ground loops
- Intrinsically safe
- Fiber optic link can extend to 2500 meters
- Industry standard Duplex LC or harsh environment ODVA LC Duplex (IP-LC) optical interfaces
- Sensor is ATEX classified as "Simple Apparatus", allowing safe use in all types of hazardous locations and explosive atmospheres, including mines, oil rigs and petrochemical plants
- Fiber optic link provides 100% electrical isolation between patient and electrical equipment
- Special non-metallic model for MRI and other applications requiring electromagnetic transparency
- Controller offers multiple built-in interfaces for maximum system compatibility, including A/B quadrature outputs, RS422/RS485, RSS232, Modbus RTU, USB and both 4-20mA and $\pm 10V$ programmable analog outputs

The MR320 series Sensors offers a wide range of size, mounting, resolution and temperature performance options::

- MR322 is a Size 58mm shaft encoder with 100/128/256/360ppr options
- MR326 is a Size 90mm shaft encoder with 100/128/256/360ppr options and IP66 environmental seal for wash down and short immersion.
- MR324 is Size 100mm high resolution hollow shaft encoder with 1024ppr resolution
- MR324 is Size 125mm high resolution shaft encoder with 1024ppr resolution
- MR328 is a non-metallic Size 58mm shaft encoder (360ppr) for MRI and other applications where electromagnetic transparency is required
- STANDARD temperature range is $-40^{\circ}C$ to $+80^{\circ}C$ (except MR328)
- EXTENDED temperature option offers extended performance over $-60^{\circ}C$ to $+150^{\circ}C$ (Models MR324 and MR326 only)
- ODVA LC Duplex (IP-LC) interface available on MR322, MR325 and MR326 series Sensors

2. Warranty Information

MICRONOR INC. warrants this product to be free from defects in material and workmanship for a period of 1 (one) year from date of shipment. During the warranty period we will, at our option, either repair or replace any product that proves to be defective. To exercise this warranty, write or call your local MICRONOR INC. representative, or contact MICRONOR INC. headquarters. You will be given prompt assistance and return instructions. Send the instrument, transportation prepaid, to the indicated service facility. Repairs will be made and the instrument returned transportation prepaid. Repaired products are warranted for the balance of the original warranty period, or at least 90 days.

2.1 Limitations of Warranty

This warranty does not apply to defects resulting from unauthorized modification or misuse of any product or part. This warranty also does not apply to Fiber Optic Connector interfaces, fuses or AC line cords.

This warranty is in lieu of all other warranties, expressed or implied, including any implied warranty of merchantability of fitness for a particular use. MICRONOR INC. shall not be liable for any indirect, special or consequent damages.

2.2 Contact Information

Micronor Inc.
900 Calle Plano, Unit K
Camarillo, CA 93012
USA

Tel +1-805-389-6600
Fax +1-805-389-6605
EMAIL sales@micronor.com
URL: www.micronor.com

In Europe:

Micronor AG
Pumpwerkstrasse 32
CH-8015 Regensdorf
Switzerland

T: +41-44-843-4020
F +41-44-843-4039
EMAIL: sales@micronor.ch
URL: www.micronor.ch

3. Specifications

3.1 MR320 Controller

Functional Specification:

Description	Specification
DIRECT Quadrature Outputs	
Bandwidth	70 kHz max. (Contact Micronor concerning modifications for higher bandwidth applications.)
Format	A/A'/B/B' RS422 Line Driver and A/B Push-Pull Outputs are Standard
DIVIDER Quadrature Outputs	
Divider Range	Programmable DIVIDER range is 2-9999
Format	A/A'/B/B' RS422 Line Driver standard (Contact Micronor if Push/Pull outputs are required)
Analog Outputs	Each output is independently programmable for <i>Position</i> or <i>Speed</i> .
Current Output:	Range: 0-24mA, Max Burden Resistance: 500Ω (24V supply)
Voltage Output:	Range: ±12V; Max Current: 5mA (2kΩ load); Short Circuit < 5s
POSITION Mode	
Internal Counter	Full-scale range of selected analog output is 1 to 8,388,607 counts (equivalent to 8,192 revolutions of MR314 1024ppr encoder) based on contents of internal counter (Direction/Sign Bit plus 24-bit counter (±8,388,607). Half-step resolution can be achieved by enabling MULTIPLIER function (x2).
Counter Hardware Set-Reset	PLC-type 24V logic input OR serial software command
SPEED Mode	Full-scale range of selected analog output can be programmed from 10 to 10,000 RPM
USB Interface	Built-in, Type B receptacle
Serial Interface	RS422/RS485 Or Modbus/RTU via J3 (Can be operated as RS232 interface with optional MR232-1 Converter Cable)
Fiber Link Length	2500 m (8200 ft) max typical Total Link loss not to exceed 12.5 dB (two way at 850 nm) For longer link applications, contact Micronor with your requirements.
Electrical Connectors	WAGO QuickConnect Plugs: J1: 12-pin (WAGO 733-112) J2: 10-pin (WAGO 733-110) J3: 6-pin (WAGO 733-106) USB Type B Receptacle

Power Supply Specifications:

Power Supply Input	+15VDC to +32VDC, 60mA During Power Up, the external power supply should be capable of delivering a momentary current surge in excess of 100 mA
+5V Output	10mA maximum load (Designed for powering MR232-1 Converter Cable)

Environmental Specifications:

ATEX Rating	[Ex op is 55°C/T6] “Inherently Safe Optical Radiation” Shall be installed in non-hazardous location
Temp Range	-5° to +55° C
Humidity	30% to 85% RH (non-condensing)
Ingress Protection	IP40

Physical Dimensions:

Mounting	35mm DIN Rail
Housing	102mm W x 102mm D x 68mm H
Weight	300g (10.5oz)

Specifications subject to change without notice

3.2 MR322 Size 58mm Sensor

Functional Specification:

Description	Specification
Resolution	Standard options are 100, 128, 256 or 360 ppr
Max Speed	Continuous operating speed
Mechanical	8000 rpm
Electrical	8000 rpm (Direct Quadrature outputs used with all Auxiliary Functions OFF) 5000 rpm (Direct Quadrature outputs used and all Auxiliary Functions ON) Auxiliary Functions are processor-dependent functions; e.g. Divider, Multiplier, Counter and Analog Outputs. Contact Micronor for more information about speed versus operational trade-offs.
Optical Interface	Duplex fiber optic pigtail with Duplex LC plug or ODVA LC Duplex (IP-LC) Receptacle
Fiber Type	MM 62.5/125µm, Graded Index, 0.275NA
Maximum Fiber Link Length	See MR320 specifications for maximum distance and optical link loss range

Environmental Specifications:

Temp Range/ATEX Classification	“Intrinsically/Inherently Safe Simple Apparatus”
STANDARD Option ATEX Rating U.S. Haz Rating	-40° to +80° C c Ex op is I/II 80°C/T6 Class I/II/III, AEx op is Group I/II/III 80°C/T6 , Zone 0/1/2/20/21/22, Division 1/2
EXTENDED Option ATEX Rating U.S. Haz Rating	-60° to +150° C c Ex op is I/II 150°C/T3 Class I/II/III, AEx op is Group I/II/III 150°C/T3 , Zone 0/1/2/20/21/22, Division 1/2
Humidity	0% to 95% RH (non-condensing)
Ingress Protection	IP 64

Mechanical Specifications:

Shaft	Ø 6mm x 5.5mm FLAT x 10mm L (Ø 0.236-in x 0.217-in FLAT x 0.393-in L)
Max Shaft Load	Radial = 80N (18 lbf), Axial = 40N (9 lbf)
System MTBF	1.786E+05 hours (20.3 years) (Bearing Life calculated at 2,500 RPM and 50% of Maximum Radial/Axial Shaft Load)
Housing	Ø 58mm x 58mm L
Weight	210g (7.25 oz)

Specifications subject to change without notice

3.3 MR324 High Resolution Hollow Shaft Sensor

Functional Specification:

Description	Specification
Resolution	1024 ppr
Max Speed	Continuous operating speed (unless otherwise noted)
Mechanical	3000 rpm continuous 3,300 rpm short term (<1 minute) 3,300 rpm max - For Quadrature Outputs Only
Electrical	3,000 rpm max - For I and V Analog Outputs activated but Divider de-activated 2,500 rpm max - For I and V Analog Outputs and Divider activated
Optical Interface	Duplex fiber optic pigtail with Duplex LC plug
Fiber Type	MM 62.5/125µm, Graded Index, 0.275NA
Maximum Fiber Link Length	See MR320 specifications for maximum distance and optical link loss range

Environmental Specifications:

Temp Range/ATEX Classification	“Intrinsically/Inherently Safe Simple Apparatus”
STANDARD Option ATEX Rating U.S. Haz Rating	-40° to +80° C c Ex op is I/II 80°C/T6 Class I/II/II, AEx op is Group I/II/III 80°C/T6 , Zone 0/1/2/20/21/22, Division 1/2
EXTENDED Option ATEX Rating U.S. Haz Rating	-60° to +150° C c Ex op is I/II 150°C/T3 Class I/II/II, AEx op is Group I/II/III 150°C/T3 , Zone 0/1/2/20/21/22, Division 1/2 IMPORTANT NOTE: At 3,000 rpm, the MR324 housing temperature rises by 25° C above ambient temperature due to bearing friction. Environmental temperature must be reduced accordingly.
Humidity	0% to 95% RH (non-condensing)
Ingress Protection	For standard through hole model = IP54 For blind hole model = IP65

Mechanical Specifications:

Shaft	Ø 38mm Hollow Shaft ID
Moment of Inertia	209E-06 kg*m ²
System MTBF	2.54E+07 hours (2893 years) (Bearing Life calculated at 2,500 RPM)
Housing	Ø 100mm x 49mm L
Weight	655g (23 oz)

Specifications subject to change without notice

3.4 MR325 Size 125mm High Resolution Sensor

Functional Specification:

Description	Specification
Resolution	1024 ppr
Max Speed	3600 rpm
Optical Interface	ODVA Industrial LC Duplex receptacle
Fiber Type	MM 62.5/125µm, Graded Index, 0.275NA
Maximum Fiber Link Length	See MR320 specifications for maximum distance and optical link loss range

Environmental Specifications:

Temp Range/ATEX Classification	“Intrinsically/Inherently Safe Simple Apparatus”
STANDARD Option ATEX Rating U.S. Haz Rating	-40° to +80° C c Ex op is I/II 80°C/T6 Class I/II/III, AEx op is Group I/II/III 80°C/T6 , Zone 0/1/2/20/21/22, Division 1/2
Humidity	0% to 95% RH (non-condensing)
Ingress Protection	IP67

Mechanical Specifications:

Shaft	Ø 12mm x 15.6mm L
Moment of Inertia	TBD
System MTBF	L10 Bearing Life at 10% of max radial and axial load at 3000 rpm: 1.410E+07 hours (1609 years)
Housing	Ø 125mm x 90mm L
Weight	1505 g (53 oz)

Specifications subject to change without notice

3.5 MR326 Size 90mm Heavy Duty Sensor

Functional Specification:

Description	Specification
Resolution	Standard options are 100, 128, 256 or 360 ppr
Max Speed	Continuous Operating Speed
Mechanical	8000 rpm
Electrical	8000 rpm (Direct Quadrature outputs used with all Auxiliary Functions OFF) 5000 rpm (Direct Quadrature outputs used and all Auxiliary Functions ON) Auxiliary Functions are processor-dependent functions; e.g. Divider, Multiplier, Counter and Analog Outputs. Contact Micronor for more information about speed versus operational trade-offs. IMPORTANT NOTE: Derate maximum speed by 100 rpm per degree Celsius when operating above 60°C.
Optical Interface Options	Duplex fiber optic pigtail with Duplex LC plug or ODVA LC Duplex (IP-LC) receptacle
Fiber Type	MM 62.5/125µm, Graded Index, 0.275NA
Maximum Fiber Link Length	See MR320 specifications for maximum distance and optical link loss range

Environmental Specifications:

Temp Range/ATEX Classification	“Intrinsically/Inherently Safe Simple Apparatus”
STANDARD Option ATEX Rating U.S. Haz Rating	-40° to +80°C c Ex op is I/II 80°C/T6 Class I/II/III, AEx op is Group I/II/III 80°C/T6 , Zone 0/1/2/20/21/22, Division 1/2
EXTENDED Option ATEX Rating U.S. Haz Rating	-60° to +150°C c Ex op is I/II 150°C/T3 Class I/II/III, AEx op is Group I/II/III 150°C/T3 , Zone 0/1/2/20/21/22, Division 1/2
Humidity	0% to 95% RH (non-condensing)
Ingress Protection	For version with fiber optic pigtail = IP54 For version with built-in ODVA IP-LC receptacle = IP65

Mechanical Specifications:

Shaft	Ø 12mm x 25mm L with 4x20mm Keyway
Max Shaft Load	Radial = 140N (31 lbf), Axial = 70N (15 lbf)
System MTBF	8.96E+05 hours (102 years) (Bearing Life calculated at 2,500 RPM and 50% of Maximum Radial/Axial Shaft Load)
Housing	Ø 90mm x 82.5mm L
Weight	615g (21.5 oz)

Specifications subject to change without notice

3.6 MR328 Size 58mm MRI-Compatible Sensor

Functional Specification:

Description	Specification
Resolution	360 ppr
Max Speed	Continuous Operating Speed
Mechanical	6000 rpm
Electrical	6000 rpm (Direct Quadrature outputs used with all Auxiliary Functions OFF) 5000 rpm (Direct Quadrature outputs used and all Auxiliary Functions ON) Auxiliary Functions are processor-controlled functions; e.g. Divider, Multiplier, Counter and Analog Outputs. Contact Micronor for more information about speed versus operational trade-offs.
Optical Interface	Duplex fiber optic pigtail with Duplex LC plug IMPORTANT NOTE: Fiber optic pigtail length must be long enough so that the semi-metallic Duplex LC plug is outside of the MRI environment.
Fiber Type	MM 62.5/125µm, Graded Index, 0.275NA
Maximum Fiber Link Length	See MR320 specifications for maximum distance and optical link loss range

Environmental Specifications:

Temp Range	Ambient laboratory environment Inherently safe optical radiation, "Simple Apparatus"
Humidity	0% to 95% RH (non-condensing)

Mechanical Specifications:

Shaft	Ø 6mm x 5.5mm FLAT x 10mm L (0.236-in OD x 0.217-in FLAT x 0.393-in L)
Max Shaft Loads	Radial = 60 N (13.5 lbf), Axial = 30 N (6.75 lbf)
System MTBF	3.01E+06 hours (343 years) (Bearing Life calculated at 1,000 RPM and 50% of Maximum Radial/Axial Shaft Load)
Housing	Ø 58mm x 58mm L
Weight	280g (9.75 oz) - With 5m Pigtail

Specifications subject to change without notice

4. Initial Preparation

4.1 Standard Contents

MR320 Controller Module will always include:

- MR320 Module with WAGO mating connectors installed (1 each: 12-, 10- and 6-pin)
- Poly bag containing WAGO Tool (233-335) and 3x Strain Relief Plates (733-128)

MR320 Sensors will always include:

- MR320 Series Sensor

Optional accessories if ordered:

- MR320 series Duplex LC Fiber Optic Cables Assemblies
- MR320C Duplex LC Mating/Bulkhead Adapter
- MR398 series Fiber Optic Cables Assemblies (Duplex LC and ODDA)
- MR232-1 RS485/422 to RS232 Adapter Cable

One set of the following is also included with any shipment with an MR320 Controller:

- MR320 Series / ZAPPY™ Installation Guide (printed copy)
- MR320 Series/ZAPPY™ Software Installation and Documentation CDRom
- MR321C Fiber Optic Cleaning Kit
- MR232-3 USB Cable

4.2 Unpacking and Inspection

The unit was carefully inspected mechanically and electrically before shipment. When received, the shipping carton should contain the following items listed below. Account for and inspect each item before the carton is discarded. In the event of a damaged instrument, write or call MICRONOR INC. in Camarillo, California. Please retain the shipping container in case reshipment is required for any reason.

4.3 Damage in Shipment

If you receive a damaged instrument you should:

- 1) Report the damage to your shipper immediately.
- 2) Inform MICRONOR Inc.
- 3) Save all shipping cartons.


Failure to follow this procedure may affect your claim for compensation.

5. Installation Guidelines

5.1 System Planning

There are two recommended steps in designing and installing the fiber optic rotary encoder.


1. **Select cable and connectors which will meet performance, reliability and regulatory/contractual requirements.** Many applications operating in harsh or hazardous locations must follow industry-specific, contractual or government regulations – i.e. mines, building codes, ATEX, etc. . Connectors and cabling may need to meet flammability, radiation, temperature, corrosion resistance, altitude, shock, vibration, and/or other specific requirements.



Insertion Loss Performance Requirements

- Use only high quality, SUPER PC epoxy-and-polish terminated connectors and termini (epoxy-less or pre-terminated connectors tend to create back reflectance/return loss performance problems).
- A high-quality optical connector should have a worst case, end-of-life insertion loss of 0.5 dB over time and all environmental effects. The typical beginning-of-life (aka out-of-box) loss should be considerably less than 0.25 dB.
- Good quality mechanical splices should not exhibit insertion losses greater than 0.2 dB.
- Good fusion splicing techniques should produce insertion losses $\ll 0.1$ dB

2. **Verify that the optical link design meets optical loss budget.** The MR320 Series ZapFREE® Rotary Encoder system has a two-way loss margin of 12.5dB to cover fiber attenuation at 850nm over distance as well as losses of inline connectors and splices.




Important Considerations for Optical Loss Budget Analysis

- In the Optical Loss Budget analysis, you must also include the loss of the primary connections to the Sensor and Controller Module. That's two interconnections – typically high quality Duplex LC connectors for standard implementations.
- Since the fiber's attenuation is higher at 850nm versus 1300nm (this is a dual wavelength system), use the 850nm loss figure (typically 3dB/km) when accounting for fiber/cable losses.

EXAMPLE.: Suppose that an installation will have a total link length of 1100 meters made up of two spans - 100m and 1000m. have a link length of 1100 meters consisting of a 100m and 1000m segments. Let's assume a worst case Duplex LC connection loss of 0.5dB and fiber attenuation of 3.5 dB/km at 850nm. The following table details the loss calculations to arrive at a predicted worst case loss of 10.7 dB - well below the MR320 system's 12.5 dB maximum system loss margin..

FEATURE	Input Fiber Loss (dB)	Output Fiber Loss (dB)	Total 2-Way Loss (dB)
MR320 Duplex LC Connection	0.5	0.5	1.0
100 meter Span (@ 3.5dB/km)	0.35	0.35	0.7
Duplex LC Interconnection of the two spans	0.5	0.5	1.0
1000 meter Span (@ 3.5dB/km)	3.5	3.5	7.0
MR324 Sensor Duplex LC Connection	0.5	0.5	1.0
TOTAL 2-WAY LOSS	Meets Optical Budget Requirements, < 12.5 dB System Margin		10.7

3. Follow industry-standard installation practices and trained fiber installers.



Follow Proper Installation Practices For Your Industry

- Different industries or applications may have standards related to fiber optic installations. Examples: BICSI for LAN and telecom installations, ISA or EU for hazardous locations, ARINC for civil and military air transport platforms, U.S. Navy for shipboard applications, SAE for generic aerospace applications, etc.
- Always follow best practices with regards to bend radius, flex, clamping and routing conventions. In fiber cable installations, excess bends and improper clamping produce additional losses that is not accounted for in the loss budget – and shouldn't be there anyway.
- Always place a dust cover over an open connector to prevent dirt from accumulating on the ferrule end.
- Always wipe a connector endface clean before mating.

5.2 Mounting the Solid Shaft Encoder Sensors


Applicable Models: MR322, MR326 and MR328 sensors

Consult reference drawing in Appendix A for most current mounting and dimensional information.

The mechanical workings of an encoder are straightforward. The rotor portion is coupled to a shaft, so that it will turn without slippage, and the encoder body is prevented from rotating so that it serves as a physical reference for the rotation of the rotor.

Here are two basic ways to mount the Shaft Encoder:

- Counter-Bored Panel Mount via Screws
- Through-Hole Panel Mount with Synchro Clamps

**Important Considerations About Encoder Hook-Up**

- Do not alter or modify the shaft otherwise the accuracy of the encoder and the dependability of the bearings and gaskets will be affected.
- Always use a flexible coupling between drive shaft and encoder shaft.
- Bearings are sensitive. Always handle the encoder with care when handling and mounting to the mechanism.
- The mechanical life of any encoder is mainly determined by the loading on the unit's bearings. As either the radial or axial shaft loading increases, bearing life is shortened. For this reason, the minimum amount of shaft loading or misalignment should always be the goal when installing an encoder.

5.2.1 Face Mount to Counter-Bored Panel

Consult encoder's reference drawing provided in Appendix A for most current mounting information, dimensions and tolerances.

Figure 1 illustrates how the encoder becomes mounted to the panel via three screws (M4 for MR322 and M6 for MR326) and to the mechanism's shaft with a flexible coupling:

- STEP 1.** Check that there are no burs on the mating shaft and that the set screws on the flexible coupling are backed off so they don't bind when slipped on the shaft.
- STEP 2.** Slide the coupling onto the mating shaft. If the mating shaft has a flat or a key way, make sure that the setscrew is aligned to land on the flat part of the shaft.
- STEP 3.** Mount the encoder to its bracket with screws. Do not tighten them all the way. Position the encoder shaft with the mating shaft so they are co-aligned with a gap of about 1/8-inch (3mm). Check the misalignment specifications for the coupling to ensure that it is not overstressed. Tighten the encoder mounting screws.
- STEP 4.** Align the flat of the encoder shaft with the flat or keyway on the mating shaft. Center the coupling over the gap between the two shafts and tighten the setscrew on the mating shaft. Wiggle the encoder shaft back and forth slightly to ensure that the coupling is not binding and it is at its free length. Now tighten the setscrew on the encoder shaft. Installation is complete.




Figure 1. Shafted Encoder Face Mount via Counter-Bored Panel

5.2.2 Thru-Hole Panel Mount with Hold-Down (Synchro) Clamps

Consult reference drawing in Appendix A for most current mounting and dimensional information.

Figure 2 illustrates how the encoder becomes mounted to the panel via three hold-down clamps. Order Micronor P/N 6099.20.651 for MR322 encoder or 6099.20.652 for MR326 encoder. Each kit is a set of 3 clamps and 3 screws. Use a flexible coupling for connecting to the mechanism's shaft.

- STEP 1.** Check that there are no burrs on the mating shaft and that the set screws on the flexible coupling are backed off so they don't bind when slipped on the shaft.
- STEP 2.** Slide the coupling onto the mating shaft. If the mating shaft has a flat or a key way, make sure that the set screw is aligned to land on the flat part of the shaft.
- STEP 3.** Mount the encoder to its bracket or panel with the Synchro clamps. Do not tighten them all the way. Position the encoder shaft with the mating shaft so they are co-aligned with a gap of about 1/8-inch (3mm). Check the misalignment specifications for the coupling to ensure that it is not overstressed. Tighten the encoder's synchro clamp mounting screws.
- STEP 4.** Align the flat of the encoder shaft with the flat or keyway on the mating shaft. Center the coupling over the gap between the two shafts and tighten the setscrew on the mating shaft. Wiggle the encoder shaft back and forth slightly to ensure that the coupling is not binding and it is at its free length. Now tighten the set screw on the encoder shaft. Installation is complete.





Figure 2. Shafted Encoder Mounting via Thru-Hole With Synchro Clamps

5.3 Mounting the Hollow-Shaft Rotary Encoder

Applicable Model: MR324

Like the MR322/MR326, the mechanical workings of the MR324 sensor is straightforward. The rotor portion is coupled to a hollow shaft and the encoder body is prevented from rotating via a flexible Tether arm or Spring Clip attached to the Stator.

Figure 3 illustrates various mounting options and hardware available for use with MR324 hollow-shaft encoders.



Important Considerations About Hollow Shaft Encoders

- Do not alter or modify the hollow shaft assembly otherwise the accuracy of the encoder and the dependability of the bearings and gaskets will be affected.
- Bearings are sensitive. Always handle the encoder with care when handling and mounting to the mechanism.
- Bearing degradation can occur if motor shaft currents are allowed to pass through the encoder bearings. While the fiber optic connection provides overall electrical isolation, it may be necessary to locally isolate the shaft by either use of an isolation insert or insulating the tether arm.
- The mechanical life of any encoder is mainly determined by the loading on the unit's bearings. As either the radial or axial shaft loading increases, bearing life is shortened. Excessive runout will cause premature bearing failure. For this reason, the minimum amount of shaft loading or misalignment should always be the goal when installing an encoder.

Consult the MR324 data sheet for detailed product description, dimensions and instructions for mounting the encoder using the optional MR314A or MR314B Mounting Kit. Generically, follow these procedures for mounting the encoder:

- STEP 1.** Check that there are no burs on the mating shaft and that the shaft length is correct for the encoder
- STEP 2.** Attach the Tether Arm to the encoder body using the supplied hardware. Slide the assembly onto the mating shaft.
- STEP 3.** Rotate the Tether Arm until it is at the correct orientation and align with the mounting feature on the shaft housing. Using the appropriate hardware to secure the tether arm in that position.
- STEP 4.** Check to make sure that the tether is still in its "unstressed" condition and then tighten the shaft clamp on the encoder. Check for excessive runout as you rotate the shaft by hand. (Excessive runout will cause premature bearing failure.) If the runout is excessive, then reinstall the encoder. Otherwise, installation is complete.









Pictures	Example of Use	Use	Pitch Circle Diameter	Order Code
		For applications with fastening points located on variable pitch circle	104-206 mm	MR314A
		For applications with high axial play	110 mm	MR314B (Use Long Spring and Pin)
		For applications with reduced mounting space	76 mm	MR314B (Use Short Spring and Pin)
		For applications with axial and radial play with low dynamics for constant rotary movement	65 mm	MR314B (Use Small Tether Bracket and Screw)

Figure 3. Hollow Shaft Encoder Mounting Options.

5.4 Mounting the Controller Module

The MR320 Controller is designed to mount on a standard 35mm DIN rail, as shown in Figure 4 below.




Figure 4. Mounting MR320 Controller on DIN Rail.

5.5 Making Optical Connection to the Controller Module

Figure 9 illustrates all connections (both electrical and optical) and controls on the MR320 Controller.

A duplex fiber optic cable is used to interconnect the Sensor and Controller. The MR320 Controller incorporates a Duplex LC receptacle while the Sensor can either feature a Duplex LC optical pigtail or Harsh Environment ODVA LC Duplex receptacle. The optical link can be a direct connection between Sensor and Controller via the Sensor pigtail or multi-segment link incorporating interconnections and splices (as long as the 2-way optical loss does not exceed 12.5 dB).

Figure 5 shows the proper method of making a Duplex LC connection. Remove the dust cap from both the connector on the cable and the receptacle on the controller. Insert the LC Duplex connector as shown. There should be a positive click when the connector is engaged properly.




Figure 5. Making Duplex LC Optical Connection to MR320 Controller.

5.6 Making Electrical Connections to the Controller Module

Figure 9 illustrates all connections (both electrical and optical) and controls on the MR320 Controller.

Electrical connections to the MR320 Controller are via three WAGO Quick-Connect plugs and USB receptacle.

A set of three WAGO Quick-Connect plugs, three strain relief plates and WAGO Insertion Tool are supplied with the Controller Module to facilitate connections to J1/J2/J3 and are cross-referenced in Figure 6 below. All three Terminal Connectors are WAGO type Mini Multi Connection System with 2.5mm spacing.



WAGO Connector Part Numbers for Terminal Connectors		
Location	MICRONOR PN	WAGO PN
J1	63-733-112	733-112
J2	63-733-110	733-110
J3	63-733-106	733-106
Tool	63-233-335	233-335

Figure 6. Cross-Reference for WAGO QuickConnect Plugs used for J1/J2/J3 Connections

These terminal connectors are non-screw connections and accept wires from AWG20 through AWG 28 or 0.5mm² to 0.08mm². The WAGO terminal blocks are a convenient way to pre-wire harnesses. To make connections, consult Figure 7 and the following steps::

1. Strip the wire approx. 0.22" (5mm to 6mm) length.
2. Insert the white operating tool into the square hole of the terminal.
3. Then insert the stripped wire all the way down and remove the operating tool.
4. When wiring completed, simply insert the WAGO plug into the appropriate interface connector (J1, J2 or J3). To remove the WAGO plug, grasp top and bottom of plug and pull to disconnect




Figure 7. How To Insert and Remove Wires From the WAGO Plug





Figure 8. Inserting/Removing the WAGO Plug From The MR320 Controller Module.




J1 Connections Real-Time Quadrature Outputs and Power Supply	
1	A+ RS422 Line Driver
2	A- RS422 Line Driver
3	GND
4	B+ RS422 Line Driver
5	B- RS422 Line Driver
6	GND
7	A Push-Pull
8	B Push-Pull
9	GND (power)
10	+Vs (power) (15V to +32V)
11	Counter RESET (24V Logic "1")
12	Shield

J2 Connections Divider and Analog Outputs	
1	Divider A+ RS422 Line Driver (5V TTL)
2	Divider A- Push-Pull
3	GND
4	Divider B+ RS422 Line Driver (5V TTL)
5	Divider B- Push-Pull
6	GND
7	GND
8	±10V Out
9	GND
10	4-20mA Out

J3 Connections RS422/485 Serial I/O plus connection for MR232-1 series Adapter Cable	
1	GND
2	+5V Out (10mA max, power for MR232-1 Converter Cable)
3	TX+ →
4	TX- →
5	RCV+ ←
6	RCV- ←

Figure 9. Connections and controls of the MR320 Controller Module

ELECTRICAL CONNECTION	DESCRIPTION
Case Shield	Connection is made through pin 12 of J1 (12-pin plug).
Power	Power connections are made through pins 9 (GND) and 10 (+15V to +32V) of J1 (12-pin plug). Observe correct polarity!
REAL-TIME Quadrature Outputs	These signals are the direct outputs of the ZapFREE® rotary encoder after conversion from optical to electrical signals. The A/B Push-Pull outputs are available through pins 7 and 8 of J1. The A+/A-/B+/B- RS422 Line Driver outputs are available through pins 1, 2, 4, and 5 of J1. Ancillary GND connections are available via pins 3 and 6 of J1.
DIVIDER Quadrature Outputs	These are the quadrature electrical outputs after going through the Programmable Divider function. DIV A+/B+ RS422 Line Driver outputs are available via pins 1 and 4 of J2. DIV A-/B- Push-Pull outputs are available via pins 2 and 5 of J2. Ancillary GND connections are available via pins 3 and 6 of J3.
USB Interface	Direct connection via Type B receptacle provided.
RS485 Serial Interface	Line driver signals available via pins 3, 4, 5 and 6 of J3. For RS232 serial communications, MR232-1 Converter Cable plugs into J3.
VOLTAGE Analog Output	This analog output is available on pin 8 of J2 and can be configured to represent position or speed (rpm). Voltage mode and scale are set using ZAPPY™ software or as commands issued over the serial interface
CURRENT Analog Output	This analog output is available on pin 10 of J2 and can be configured to represent position or speed (rpm). Current mode and scale are set using ZAPPY™ software or as command issued over serial interface
POSITION COUNTER RESET Input	This external control signal is available on pin 11 of J1. This signal line allows the 24-bit Internal Counter to be reset to a pre-programmed counter value when the input is changed from logic 0 to logic 1 (High, +24V). The reset value is factory preset to 0 (zero). The customer may change this reset value to any number by setting the appropriate parameter via ZAPPY™ configuration software via serial interface commands. Section 5.9 shows how to perform a manual RESET.



Important Power Connection Warnings!

- Always observe correct polarity of the power supply connections or damage to the Controller module may occur. Input range is +15 to +32VDC.
- While the Controller is protected against cross polarization of the power supply connections, the unit will **not operate** if wrongly connected. The unit may be damaged by connecting a power supply to an input or output.
- There is an initial in-rush current in excess of 100mA. The power supply must be capable of handling that current.

5.7 Fiber Optic Cable, Connections and Routing

A complete and functional MR320 Series Fiber Optic Encoder System consists of a MR320 Controller and MR320Series Passive Sensor connected by an optical link. The fiber link shall be comprised of standard 62.5/125 Graded Index multimode fiber. Terminations may be either Duplex LC or ruggedized ODVA LC Duplex (IP-LC) depending on the application and expected environment.

The following figures illustrate some of the optical link configurations possible. For harsh environments, Micronor recommends the ruggedized IP66/IP67-rated ODVA LC Duplex (IP-LC) interface as shown in Figure 11. For application assistance, please contact Micronor sales and technical support.




Figure 10. Typical MR320 Series Fiber Optic System connections using Sensor with Duplex LC Pigtail




Figure 11. Typical MR320 series system using Harsh Environment ODVA LC Duplex (IP-LC) Connections



Fiber Optic Connector Optical Performance Requirements

- Always use high quality Duplex LC or ODVA IP-LC connectors and terminations. High precision single mode connectors are not much more expensive than multimode versions. "Epoxy and Polish" connectors are preferred over "hot melt" or other quick termination style connectors.
- Insertion loss < 0.5dB measured at 850nm and 1300nm
- Polished to single mode endface geometry specifications per TELCORDIA GR-326-CORE

For relatively benign industrial environments, sensors with Duplex LC optical pigtails and standard MR320-Duplex LC link assemblies are usually adequate.

For harsh environments, sensors with ODVA IP-LC receptacles and links comprised of heavy duty ODVA IP-LC environmental assemblies are recommended. Cabling should also be selected that is certified for the intended temperature range, environment and application. Sensors must be specified that have adequate shaft seals and IP rating. For example:

- Oil rig equipment must be resistant to mud oil used to lubricate drilling apparatus


- Mining applications are typically dusty environments and may also require cabling meeting MSHA standards.
- Other industrial and process environments may require resistance to harsh and corrosive chemicals such as detergents, acids, hydraulic fluid, jet fuel, etc.

Before connecting the optical link between the Controller module and Sensor, the cable should be routed and installed such that:

- Proper bend radius specifications are not exceeded; and
- There is no pinching or other deformation of the optical cable at any point.
- Follow best installation practices which meet or exceed applicable industry standards such as the BICSI Information Transport Systems Installation Manual (for commercial datacom installations), ARINC 628 Part 6 or ARINC 806 (for avionics applications), SAE AS5088 (for aerospace), etc.

Proper functioning of a ZapFREE® Fiber Optic Rotary Encoder is very dependent on having clean optical connections. Before making any optical connections, you should make sure that:

- Connector ends have been properly cleaned and visually inspected before making connection to the ZapFREE® hardware.
- When required, thorough cleaning should be performed with reagent grade (99%) Isopropyl Alcohol (IPA) and dry lintless wipes (e.g. Kimwipes). Field portable cleaning tools such as the CLETOPS are suitable when only surface cleaning is required.
- For visual inspection, a 200x or 400x high quality fiber optic connector inspection microscope is recommended. Dirty or damaged connector ends can also damage the connector being mated to.
- Unmated connectors should always have dust caps installed to protect the polished ends from airborne contaminants or damage from mishandling.




Fiber Optic Connector Cleanliness Is Important!

- Always clean and visually inspect connector ends before mating to the ZapFREE® equipment.
- Always cap unmated connectors.
- Fiber optic connectors do not require maintenance. That is, do not disconnect for the sole purpose of examining the ends. *If it ain't broke, then don't fix it!*

5.8 First Time Start-Up

After making all connections to Controller and Sensor, perform the following Start-Up procedure:

- Step 1: Turn on power. PWR LED should be ON.
- Step 2: Follow the Manual Reset procedure described in Section 5.9



PWR LED Indicator and Error Code Interpretation

The Controller goes through an internal Calibration Cycle every 60 seconds. Thus, every 60 seconds a single blink of the PWR LED can be observed. If at any time, the PWR indicator blinks more than once, then count the number of blinks and consult the Error Table under the Troubleshooting section.


5.9 Manual Gain Calibration (Manual Reset)

If after operating (at a rotation of at least 50RPM), the encoder will not function properly - then a manual reset is necessary. This is not a malfunction of the unit. The issue is simply that the received optical power is currently below the detection range of the unit and the unit must recalibrate its optical gain levels. This step may only be necessary after initial installation.

To perform a Manual Reset, follow this simple procedure:

- STEP 1: Rotate input shaft of Sensor..
- STEP 2: While rotating shaft, momentarily depress the Reset button as shown in Figure 12
- STEP 3: Stop rotating.

When you press the reset switch, the POWER LED will turn OFF as long as the switch is pressed. You may press the switch as many times or as long as you wish. However, a proper calibration will only occur when the encoder is in motion while the reset switch is being depressed.





ZAPPY TOOLBAR MENU	DESCRIPTION
HOME	Restores ZAPPY™ HOME page with current software version information.
LOAD PARAM	Allows a pre-existing setup file of encoder parameters to be downloaded into the ENCODER table view window.
SAVE PARAM	Allows the existing ENCODER table view parameters to be saved to a file for later access via LOAD PARAM function
ENCODER	Displays encoder parameters in editable table format. From this mode, LOAD PARAM, SAVE PARAM, UPLOAD TO PC and SAVE TO MR320 functions are enabled and can be accessed.
UPLOAD TO PC	Downloads the current parameters from the connected Controller and overwrites the ENCODER parameter view.
SAVE TO UNIT	Uploads the current ENCODER parameter view to the connected MR310 or MR320 Controller module.
OPERATE	Accesses the OPERATE view which displays current encoder status, including speed and position counter. This function is intended for demo use only and does not serve any other purpose
DIAGNOSTICS	Provides access to various internal controls and hardware status, including voltage test, optical source control, slit time measurements, internal DAC, and input amplifier.
INSTRUCTIONS	Short form instruction reference for the MR320 Encoder System
EXIT	Close ZAPPY™ program.

Figure 13. ZAPPY™ HOME page and Tool Bar description

5.11 Initial Performance Verification with ZAPPY™

If you are planning to use the encoder in “pure” hardware mode (that is, using the Direct Quadrature Outputs only), then using the ZAPPY™ software is not necessary – but highly recommended under these conditions:

- Performance verification upon receipt
- To take advantage of the numerous built-in Auxiliary Functions that the MR320 Controller offers.
- If the MR320 module will be used under USB or Serial Interface control - to become familiar with the various programmable functions

The ZAPPY™ software is designed for RS232 communication with the MR320 module via a PC running WINDOWS (XP, Vista or 7) and .net Framework installed and connected using either the optional MR232-1 RS422/RS485-to-RS232 Adapter Cable or USB cable.

ZAPPY™ Software installation and connection:

- STEP 1. Install ZAPPY™ software on the target PC.
- STEP 2. Connect PC to MR320 Controller via either USB cable *or* (2) MR232-1 cable (connecting between J3 and PC's COM1 serial port) .
- STEP 3. Apply power to the MR320 and start up the ZAPPY™ software.
- STEP 4. HOME page appears if PC and Controller are communicating properly -as shown in Figure 13

IMPORTANT NOTE FOR USB USERS: *If you are installing ZAPPY™ for the first time on a particular PC* , it may take a 1 or 2 more program start-ups until ZAPPY™ and the PC are in sync and communicating. Each time you must disconnect the USB cable and completely exit the ZAPPY™ program - then plug in USB cable and then start ZAPPY™ again. The reason is that a sequence of events need to occur: FTDI driver installs, Windows loads USB Serial Interface driver, Windows assigns COMx port to USB and then ZAPPY need to find this particular COMx port. This COM port assignment is usually COM3 or higher.

Select [UPLOAD TO PC] to load the current Encoder parameter values from the Controller into the Encoder Table View as shown in

- STEP 5. Figure 14. If there is no serial communications connection, you will experience a “Communications Timeout” and you will need to troubleshoot the serial interface per Section 7.2 Interface.

Parameter Name	Register	Cmd Mode	Unit	Min	Max	Value	Default
Device Name	16	Read_Only	-	-1	-1	MR320	
Firmware Version	17	Read_Only	-	-1	-1	2.01	
Serial Number	18	Read_Only	-	0	10000000	1011	
Address	12	Read_Write	byte	17	255	234	234
Resolution	10	Read_Write	counts	96	1024	1024	180
Cal Interval	11	Read_Write	3s step	1	200	84	84
Duty Cycle Adjust	1A	Read_Write	-	0	128	12	105
Divider	21	Read_Write	counts	2	8192	3	3
Voltage Mode	23	Read_Write	-	0	2	0	0
Voltage Scale	24	Read_Write	RPM	10	8388607	1000	1000
Voltage Filter	25	Read_Write	ms	1	128	32	32
Current Mode	26	Read_Write	-	0	6	5	0
Current Scale	27	Read_Write	RPM	10	8388607	720	0
Current Filter	28	Read_Write	ms	1	128	2	1
Pos. Reset Mode	29	Read_Write	-	0	1	0	0
Quad Multiplier	2A	Read_Write	-	0	1	0	0
Direction	2B	Read_Write	-	0	1	0	0
Hrdwr Reset Point	2C	Read_Write	counts	0	8388607	0	0
Reset on Count	2D	Read_Write	counts	0	8388607	0	0

Figure 14. ENCODER Table View Screen.

Review the table contents and make any necessary changes to the parameter setup. Given the sample screen shown in

STEP 6. Figure 14, let's say that the existing encoder setup needs to be modified because the actual encoder has a resolution of 100 ppr. Simply type "100" followed by "↵" (ENTER) over the VALUE field for RESOLUTION.

STEP 7. If there are any parameter changes, then select [SAVE TO UNIT]. These values will be transferred to the MR320 and stored in non-volatile memory.

Next, let's test the encoder in actual – but manual – operation using the OPERATE and DIAGNOSTICS functions:

- STEP 1.** Select [OPERATE] mode and observe the initial static screen display similar to Figure 15. Adjust RPM METER SCALE setting as desired by writing into the field. Click on [RESET] to zero the POSITION COUNTER.




Figure 15. Initial OPERATE Screen if encoder is inactive.

- STEP 2.** An initial check would be to deliberately and semi-precisely turn the encoder shaft for one revolution and note if the correct number of counts is displayed. (HINT: A little adhesive tape flag formed around the encoder shaft would provide some degree of finger control.) An active [OPERATE] screen is also shown in Figure 16.




Figure 16. OPERATE Screen displays Real-time Encoder Operation.

STEP 3. Select [DIAGNOSTICS] to view various monitoring points within the MR320. Figure 17 shows the initial screen or else when the encoder is not moving. When the encoder is still, the system cannot take a snapshot of these internal points since there is no slit-to-slit movement - hence the red-framed **RPM TOO SLOW** message. Depressing [DIAGNOSTICS] tab while the encoder is rotating provides a snapshot of the internal monitoring points as shown in Figure 18. Repeatedly clicking on [DIAGNOSTICS] will update the entire set of readings while the individual diagnostic groups (Voltage Test, Optical Sources, Slit Period Measurement and Input Amplifier) which can also be updated individually. A brief explanation of the relevant diagnostic fields follows on the next page.




Figure 17. Initial DIAGNOSTICS Screen when encoder is inactive.





Figure 18. DIAGNOSTICS Screen displays internal operating points when encoder is active.



Manual Override Of Certain Parameters In DIAGNOSTICS Mode

The [Diagnostics] view allows certain internal parameters to be overwritten for diagnostic and troubleshooting purposes – e.g. CH A/B optical sources, Analog outputs and the internal Amplifier Gain factors.

DIAGNOSTICS Field Name	DESCRIPTION
Optical Receiver	<p>A and B quadrature signals correspond to Channels A (1300nm) and B (850nm) respectively. The internal optical receiver parameters are measured via a Peak Detector circuit. To measure properly, the encoder must be turning at least 100 rpm (same as required for CALIBRATE mode) for the measured values to be comparable to the acceptance range shown to the right. If the encoder is either not or turning too slow in this mode, you will see the red-framed [RPM - TOO SLOW] message.</p> <p>The Amplifier Gain and Peak optical power values are measured for each optical channel. The Gain value is modified by the periodic Calibrate mode which adjusts for any changes in optical power. Typically, the Gain values ranges from 3 to 20 and the optical power should fall within the range of -25.5 dBm to -33 dBm. “Hot” (or high power) optical transmitters are possible.</p>
Power Supply Voltages	Measures internal voltage reference as well as internal +5V and +12 supplies.
ANALOG Outputs	The DAC output (0..4095) of both the Voltage and Current analog outputs is measured and shown. The output value will depend on the Mode, Scale and Filter settings for that analog output (see Encoder table view per Figure 14). For example, if the encoder is stationary (0 RPM), Current Mode=0 (bipolar output for 0-24mA with 12mA being mid-scale value of 0), Current Scale=100 (100 RPM), Current Filter set to any value, then the DAC output will be 2048 (half scale) and the actual current output will be 12 mA (0 RPM).
Speed Measurement	The encoder measuring speed by evaluating the real-time slit-to-slit time period. This field displays time and frequency values corresponding to current shaft speed. Manually spinning the encoder shaft by finger can usually achieve 50-200 RPM but results from sample to sample may vary widely.
Calibration	Both sources should normally be checked to indicate ON. CH A and CH B correspond to 1300nm and 850nm, respectively. If either of the sources is turned off, then the VOLTAGE TEST and INPUT AMPLIFIER fields for that channel will corresponding reflect its nearly zero V output state. Turning one of the sources Off will suspend normal MR320 operation as well as initiate a red button labeled [RESET HARDWARE MODE] . Clicking this button will restore the MR320 to normal operation with all sources On.
Diagnostic Report	This function allows the various monitoring points to be saved to a file. The active status information can then be forwarded to the customer's engineering group or Micronor to help troubleshoot any encoder system problems that might arise.




Figure 19. INSTRUCTIONS Screen View offers Online Instructions and Reference Information.


6. Operation and Description of Functions

In its most basic operating mode, the ZapFREE® Fiber Optic Encoder System simply replaces a conventional rotary encoder and provides same real-time quadrature outputs – yet offers BOTH RS422 line driver and push-pull signals in a single unit). If you plan to use the ZapFREE® Encoder System in this fashion, you may simply connect the units as described in Section 5.8 First Time Start-Up - no further setup (ZAPPY™ software set-up, etc.) is required.

The MR320 Controller Module does not face the space and environmental limitations of conventional optical rotary encoders - where all optoelectronics must be packaged into the sensor housing. Consequently, the module offers an extremely useful set of Auxiliary Functions and Auxiliary I/O that offer functionality beyond the capabilities of conventional encoders:

- **DIVIDER** function provides both A/B Line Driver and A/B push-pull quadrature outputs



QUADRATURE DIVIDER (Reg 21) : The programmable divider output allows the user to divide the quadrature signals produced by the encoder.



n may be any integer number from 2 to 16383. Value 0 disables this function

NOTE: It is recommend that this function be disabled if not being used.

- **ANALOG** outputs: Both fully programmable 4-20mA and $\pm 10V$ outputs



Speed Limitations Of The Controller Module

The ZapFREE® encoder can operate at speeds well above 10,000 RPM (depending on model and resolution of encoder) using the Controller's Direct Quadrature outputs. However, the **Auxiliary Functions** (Divider and Programmable Analog Outputs) are processor limited and will shut off when the encoder frequency is higher than 50 kHz.

Auxiliary Functions can potentially be used at higher speeds with certain operational tradeoffs. Contact Micronor to discuss your application and needs.

Summary of Auxiliary Functions integrated into the MR320 controller firmware. These functions require use of ZAPPY™ software to set-up (mode, scale, etc.).

AUXILIARY Function	Features
Current Output tracking RPM	<ul style="list-style-type: none"> Scalable from 10 to 10,000 RPM full scale Up to 4mA over-range indication Mode 0: 4mA to 12mA to 20mA (with overrange and underrange) Mode 1: 0mA to 20mA uni-polar (with overrange) Mode 2: 4mA to 20mA uni-polar (with overrange) Programmable Output Low Pass Filter 2ms to 1s
Current Output tracking Position Counter	<ul style="list-style-type: none"> Scalable from 1 to $\pm 8,388,607$ counts Up to 4mA over-range indication Mode 3: 4mA to 12mA to 20mA (with over-under-range) Mode 4: 4mA to 20mA uni-polar (with overrange) Mode 5: 0mA to 20mA uni-polar (with overrange) Mode 6 : 4mA to 20mA counter window operation
Voltage Output tracking RPM	<ul style="list-style-type: none"> Scalable from 10 to 10,000 RPM full scale $\pm 10V$ with 2V over-range indication ($\pm 12V$)

	<ul style="list-style-type: none"> • Drives load down to 2k Ohm • Mode 0: -10V to 0V to 10V (with 2V over-under-range) • Mode 1: 0V to 10V uni-polar (with 2V over-range) • Programmable Output Low Pass Filter 2ms to 1s
Voltage Output tracking Position Counter	<ul style="list-style-type: none"> • Scalable from 1 to 8,388,607 counts • $\pm 10V$ with 2V over-range indication ($\pm 12V$) • Drives load down to 2k Ohm • Mode 2: -10V to 0V to 10V (with 2V over/under range)
Frequency Divided Quadrature Output	<ul style="list-style-type: none"> • Divider is programmable from 2 to 16,383 • Independent Line Driver Output from original Quadrature signal • Maintains full quadrature accuracy and direction information.
Real-Time Position Counter	<ul style="list-style-type: none"> • Maintains accurate position count • Counter depth is 24-bits (23-bits plus sign, $\pm 8,388,607$) • May be polled during operation via USB or Serial interface • Output scaleable via analog outputs
RPM Measurement	<ul style="list-style-type: none"> • RPM with better than 0.5% accuracy can be polled via USB or Serial Interface

6.1 Block Diagram

Explanation of System Functions:

To understand the functionality of the ZapFREE® Fiber Optic Encoder System, it is best to look at the functional block diagram shown in Figure 20.

The design philosophy emphasizes reliability and, thus, the signal path from encoder to the real-time quadrature output is implemented entirely in hardware. Even if the microprocessor malfunctions, the actual quadrature signal will still accurately track. (Of course, we do not recommend operating the unit when the microprocessor indicates an anomaly.)

The Controller emits two optical signals at differing wavelengths (850nm and 1300nm) via the Transmit fiber to the Sensor. Rotation sensing is accomplished by splitting the two optical signals into to their individual wavelength components. These two signal paths are direction- and speed-dependent modulated and sent back to the MR320 Controller via the Receive fiber. The optical receiver then separates out the two signals into their respective wavelengths and convert each to an analog electrical signal, individually representing either the A or B quadrature signal. However, the signal must first be amplified before it can be digitized.

The analog output of each channel is routed to a peak converter and thus when the encoder rotates the microprocessor can accurately determine the maximum received signal and adjust the voltage gain for each signal channel.

The power calibration inside the microprocessor determines when the power level is outside a safe range and will 'recalibrate' the gain of each input amplifier. This typically happens every one minute. However if the encoder is not rotating no gain calibration is being performed.

The analog voltage for each channel is compared to a known level and via comparators A and B the quadrature signals are digitized. Quadrature outputs are available in both RS422 line driver and push-pull electrical format.

The current output, voltage outputs are all generated by the microprocessor via the two 12 bit D/A converters. The divided output comes directly from the microprocessor and routed via the line driver buffer to the terminal. Output configuration may vary depending on application. Consult with MICRONOR service personnel.




Figure 20. Block Diagram of the MR320 Series Fiber Optic Encoder System.

The microprocessor measures the Speed (RPM) by measuring the elapsed time between encoder periods. The internal timer resolution is 200ns providing accuracy to very high speeds. The encoder period is averaged over 800µs and calculated using a formula:

$$V[\text{rpm}] = 60 / (t[p] * n)$$

Where: $V[\text{rpm}]$ = speed in revolutions per minute
 $t[p]$ = time elapsed for one period
 n = number of slits in encoder wheel (256 typ.)

Note: Even though the unit can measure speed values accurately to less than 0.5RPM the analog outputs have a useful measurement range from 0.5% to 110% of the scale value as defined by the user.

Output Update Rate: Each D/A converter output is updated every 800 μ s. However the user must keep in mind that the speed value is derived from the elapsed time between passing slits of the encoder wheel. At slow speed the update rate can only be as fast as the time period between passing slits.

6.2 Firmware Functions and Programming

The MR320 Controller provides a host of auxiliary functions that the user may choose to use. To configure any of these special functions (such as an analog output) requires the supplied ZAPPY™ software running on an IBM Compatible PC running Windows (XP, VISTA or 7) with an available USB or RS232 serial interface port. ZAPPY™ can also be used to verify installation and proper encoder system operation as well as perform diagnostics and assist troubleshooting.

6.2.1 Serial Communications Interface Specification

At any one time, the MR320 Controller can support one of four modes of serial communications using ISO 1745 protocol specification :

- RS422/RS485
- RS232 (Requires optional MR232-1 Converter Cable and available COM Port)
- Modbus/RTU (Contact Micronor for Modbus instructions)
- USB


The serial interface is set up as follows:

- Full-Duplex Single addressable bus interface (Factory Address = 234)
- 9,600 baud rate
- 1 Start Bit
- 8 Data Bits
- 1 Stop Bit

Factory Standard Address is set to Hexadecimal EA (234 decimal).

The command format and responses of the MR320 Controller follows the ISO 1745 specification.

For detailed programming instructions please refer to Sections 6.3 through 6.5 in this manual.




How The USB - Serial Emulator Works

The USB interface utilizes the Future Technology Devices International (FTDI) interface chip www.ftdichip.com. This chip communicates via USB, but within the PC emulates a serial COM port. When ZAPPY™ is installed, the appropriate FTDI driver is installed on the PC and the conversion from USB to Serial is completely transparent to the user. When communicating via USB, the MR320 Controller operates at a fixed 9600 Baud and base bus address settings.

6.2.2 Communications Protocol

The MR320 Controller incorporates a serial interface with RS422/RS485 level signals. A number of commands allow for configuring the operational parameters of the Controller while other commands are specifically meant for diagnostics used during setup, maintenance and troubleshooting. An RPM and Counter command are available to retrieve speed and position data while the encoder is running. The format for the commands and responses in general follow the ISO 1745 specification.

The MR320 implements a limited set of Modbus compatible functions. Contact Micronor for information on how to use the Modbus interface



What Is ZAPPY™ Setup Software?

ZAPPY™ is a user-friendly setup program provided free by Micronor. Typically ZAPPY™ is used one-time to configure the parameters for any MR320 Auxiliary Functions that are to be used in the customers application (analog outputs, etc.). The software runs on Windows (XP, Vista or 7) with .net Framework installed. Unless you plan to connect the MR320 to your own computer equipment for real-time digital data retrieval, you do not need to become familiar with the Communications protocol described herein.

There are three categories of commands:

- Configuration for Parameter Setup
- Commands for retrieving operational values such as RPM Counter
- Diagnostic commands for reading and setting hardware status.

Configuration commands are those that are intended to be executed once either in the factory or during initial setup by the customer. Although these commands can be executed at any time, they generally affect system parameters that only need to be setup once.

User commands are those that are intended to be executed any time during normal system operation.

Diagnostic commands are those that are intended to be used by trained technicians for setting and trimming the hardware or troubleshooting in the field.

All commands utilize certain control characters as defined by the ISO 1745 spec. The control characters and their designations are shown below:

STX:	Control character ^B, hex 02
ETX:	Control character ^C, hex 03
EOT:	Control character ^D, hex 04
ENQ:	Control character ^E, hex 05
ACK:	Acknowledge, hex 06
NACK:	NOT Acknowledge, hex 07
BCC:	Block Check Character (an XOR sum of data)

Within each of the three categories of commands are two types of commands:

- 1.) Data Setup
- 2.) Data Request.

All commands have a Data Request type with an accompanying Data Return.

Commands that have a Data Setup type are used to establish a system operational parameter (e.g. setting the Voltage Output Scale).

The formats for each of the two command types and the data return are standard for all commands. The formats are:

Data Setup: <EOT> A <STX> r data <ETX> <BCC>

A : The MR320 address (default of EA, settable by the user)

- r : Register number of the item being accessed
The Register number is really the command. i.e. number 22 is used to set the voltage scale
- Data : is the parameter to be written to the register . Parameters must be within valid range to be accepted.

Data Request: <EOT> A r <ENQ>

- A : The MR320 address (default of EA, settable by the user)
- r : Register number of the item being accessed (requested)
The Register number is really the command. i.e. number 22 is used to get the voltage scale

Data returned by the MR320 :

<STX>r data <ETX> <BCC>

- r : Register number of the value being returned ASCII Format and Hexadecimal.
- Data : Value being returned in ASCII format

6.2.3 The Block Check Character <BCC>

The Block Check Character is used to test the transmissions for any potential errors. The <BCC> is derived by applying a bitwise eXclusive OR (XOR) over the specified transmitted bytes. The recipient must perform the same function and compare the result with the sent <BCC> value. If the values match the transmission succeeded without errors.

The string of bytes included in the <BCC> begins with the byte immediately following <STX> up to and including the <ETX> byte.

Example Transmission:

<EOT> EA <STX> 24500 <ETX> <BCC>

The corresponding Hex bytes are:

EOT	Dev. Addr.		STX	Reg. Addr.		data			ETX	BCC
04	45	41	02	32	34	35	30	30	03	30

XOR Sum Of These Bytes
Equals
<BCC>

NOTE: The shaded bytes are included in the calculation of the <BCC>. In the above example, 32.XOR.34.XOR.35.XOR.30.XOR.30.XOR.03 equals the <BCC> value of 30.

If the MR320 receives a bad <BCC>, then it will respond with a <NACK> character.

6.3 Configuration Commands and Parameters

The following three tables describe the commands recognized by the MR320. The format for the commands as they are sent to the MR320, and the format for the data strings returned from the MR320 are the same regardless of the command. All that changes is the register number in the command and the data that is either written or read.

Each table has the following columns:

Title	Description of the command function
Reg	The register number needed in the command (as indicated by 'rn' above).
Read/Write	Indicates whether or not the register can be read and/or written to R/W = read and write RD = read only WR = write only
Range	The valid range of data that can be written by a Data Setup command, or is returned in the Data Return following a Data Request.
Default	The factory default setting of this particular parameter
Saved	Indicates whether the data is saved in EEPROM when the save command is initiated. If this column is 'NO', the data cannot be saved to the EEPROM. In most cases any data that can actually be set by the user is saved.
Description	A short explanation of the command function including information about acceptable data range. Parameter functions are described in more detail after the summary tables.

The term n/a means not applicable.

6.3.1 Configuration Commands (Registers 10-19)

These commands are used to establish system operational configuration and calibration. In general these parameters should not be changed by the user. It is possible however to do 'tricky' things. For instance the user may change the number of encoder slits and thus get fractional scaling for the analog outputs.

Title	Reg	Read/Write	Range	Default	Saved	Description
Resolution	10	R/W	95 – 10000	180	Yes	Sets the number of slits in the encoder, used for RPM calculations.
Calibration Interval	11	R/W	1 – 200	84	Yes	Sets the time interval for performing gain calibration. The value passed is multiplied by 2.55504 seconds to determine the actual time interval.
Encoder Address	12	R/W	17 – 255	234	Yes	Sets the MR320 serial address for commands. The value is entered in decimal with this command, but is sent as hex when sending commands to the device.
Operating Params	13	R/W	1 – 3	n/a	n/a	Allows user to set or restore operational parameters. 1 = Save current parameters to EEPROM 2 = Restore Power Up parameters (from EEPROM) 3 = Restore Factory Defaults (does not save to EEPROM). Return values are 0 (if last command was a restore) or 10+ if last command was save to EEPROM. Value indicates parameter presently being saved. When a save command is issued, the device will only respond to a data request to this register. All other commands will be NACK'd until the write is complete.
Command Status	14	RD	n/a	n/a	n/a	Returns the status of the last issued command
System Status	15	R/W	n/a	n/a	n/a	Returns the system error status, using a Setup command clears errors.
Device Name	16	RD	n/a	n/a	n/a	Returns the ASCII string device name (MR320)
Version	17	RD	n/a	n/a	n/a	Returns the ASCII string of the software version form MM.mm
Serial Number	18	RD	n/a	n/a	n/a	Returns the ASCII serial number of the device.
Reset	19	R/W	n/a	n/a	No	Causes a soft reset of the MR320
Duty Cycle Adjust	1A	R/W	80-180	105	Yes	Typically it should be left between 100 and 110, An oscilloscope is required to adjust the setting.

6.3.2 User Commands (Registers 20-2A)

These commands are typical commands the user will utilize during installation or normal system operation.

Title	Reg	Read/Write	Range	Default	Saved	Description
Counter	20	R/W	-16777215 – 1677215	n/a	No	Obtains the value in the encoder counter. This is a 32-bit value. The user can reset the counter by sending a 0 with the Data Setup Command.
Quadrature Divider	21	R/W	1 – 256	3	Yes	Sets the divide ratio for the programmatic encoder output pulses, e.g. if a value of 8 is set, each time eight quadrature input cycles occur, a single quadrature output cycle will be generated.
RPM	22	RD	0 – 10000	n/a	No	Reads the signed RPM. If the encoder is turning counter clockwise, the RPM is preceded by a minus sign '-'. If the encoder is turning clockwise, the RPM is reported as simply a number. The reported number is the actual RPM * 100.
Voltage Mode	23	R/W	0 – 1 (SPEED) 2 (POSITION)	0	Yes	Establishes the output mode of the voltage output. 0 = SPEED mode with bipolar $\pm 12V$ output range 1 = SPEED mode with unipolar 0-12V output range 2 = POSITION mode with bipolar $\pm 12V$ output range
Voltage Scale	24	R/W	0 – 10000 (SPEED) 0-9000000 (POSITION)	1000	Yes	Establishes the scale used for the voltage output. Regardless of Voltage Mode setting, +10V output always represents the positive VOLTAGE SCALE setting. If Voltage Mode set for SPEED, the maximum entry is 10,000. If entering a larger Scale value >10,000, the MR320 will send an error signal and reset the Scale value to 10,000. If Voltage Mode set for POSITION, the maximum entry is 9,000,000. The entered value establishes what position/counter value will produce an output $\pm 10V$ (sign depends on direction).
Voltage Filter	25	R/W	0 – 256	32	Yes	Must be power of 2 (1, 2, 4, etc) If input is not power of two then parameter is accepted and converted to the next power of two.
Current Mode	26	R/W	0 – 2 (SPEED) 3 – 5 (POSITION)	0	Yes	Sets the mode of the current output. 0 = For SPEED bipolar output range 0-12-24 mA (where 12mA represents 0rpm). 1 = For SPEED unipolar output range 0 - 24mA (where 0mA represents 0rpm)

						<p>2 = For SPEED unipolar output range 4-24mA (where 4mA represents 0rpm)</p> <p>3 = For POSITION bipolar output range 0-12-24mA (where 12mA represents zero position/counter value)</p> <p>4 = For POSITION unipolar 0-24mA range (where 0mA represents zero position/counter value)</p> <p>5 = For POSITION unipolar 4- 24mA output range (where 4mA represents zero position/counter value)</p> <p>6 = For POSITION 4- 24mA output range window mode.</p>
Current Scale	27	R/W	<p>0 – 10,000 (SPEED)</p> <p>0-9,000,000 (POSITION)</p>	0	Yes	<p>Establishes the scale used for the current output. Regardless of Current Mode setting, 20mA output always represents the positive CURRENT SCALE setting.</p> <p>If Current Mode set for SPEED, the maximum entry is 10,000. (RPM) Valid scales are 10 to 10,000. If entering a larger Scale value >10,000, the MR320 will send an error signal and reset the Scale value to 10,000.</p> <p>If Current Mode set for POSITION, the maximum entry is 9,000,000 counts, The entered value establishes what position/counter value will produce an output of 20mA</p> <p>NOTE: 0 turns off current output.</p>
Current Filter	28	R/W	0 – 256	1	Yes	<p>Must be power of 2 (1, 2, 4, 8, etc)</p> <p>If input is not power of 2, then parameter is accepted and converted to next power of 2.</p>
Counter Reset Mode	29	R/W	0 – 1	0	Yes	<p>Defines how the hardware input resets the internal counter.</p> <p>0 = Edge Triggered, resets the counter at the rising edge</p> <p>1 = Debounced Trigger when state changes from 0 to 1 after 60ms debounce time. (used for switch or relay input)</p>
Counter Multiplier	2A	R/W	0 - 1	0	Yes	<p>Internal counter increments using either a full or half cycle of the quadrature signal.</p> <p>0 = Full cycle counts</p> <p>1 = Half cycle counts (x2 multiplier)</p> <p>Note: This Aux Function only affects POSITION mode operation of the analog outputs.</p>
Encoder Direction	2B	R/W	0 - 1	0	Yes	<p>Defines output results based on turning direction of the encoder</p> <p>0 = when CW outputs are positive</p> <p>1 = reversed outputs</p> <p>Note: quadrature outputs are not affected.</p>
Hardware Reset Value	2C	R/W	0-9,000,000	0	Yes	Counter will be preset to this value when the hardware input changes from logic 0 to logic 1.
Reset On Count	2D	R/W	0 -9,000,000	0	Yes	Internal counter resets to 0 when this value is reached.

6.3.3 Diagnostic Commands (Registers 30-39)

These commands are used when servicing the MR320 either in the field or in-house.

Title	Reg	Setup	Range	Default	Saved	Description
ADC Read	30	R/W	0-4	n/a	No	Performs a read of the indicated ADC channel. The value is obtained by sending a Request. 0 = Channel A peak signal 1 = Channel B peak signal 2 = 2.5V channel reference voltage 3 = +5V channel 4 = +12V channel
Channel A Reading	31	No	n/a	n/a	No	Returns the most recent Channel A reading.
Channel B Reading	32	No	n/a	n/a	No	Returns the most recent Channel B reading
Pot A State	33	R/W	0 – 128	n/a	No	Writes the value to the Channel A gain pot. If a Request is issued, the current pot A value is returned, and a read of the pot initiated.
Pot B State	34	R/W	0 – 128	n/a	No	Writes the value to the Channel B gain pot. If a Request is issued, the current pot B value is returned, and a read of the pot initiated.
Encoder Period	35	RD	0 – 16,777,215	n/a	No	Reads the encoder period as detected on Channel A
Voltage DAC	36	RD	0 – DAC Range	n/a	No	Reads the actual setting of the Voltage DAC Value = 0 - 4095
Current DAC	37	RD	0 – DAC Range	n/a	No	Reads the actual setting of the Current DAC Value = 0 - 4095
Operating Mode	38	R/W	0 – 2	n/a	No	Sets the system operating mode. 0 = Normal 1 = Forces a gain pot calibration to occur (same as 'Cal' button being pressed). Following cal, mode returns to Normal. 2 = Sets the system to optical calibration mode. Refer to Section 7 Maintenance and Service for a detailed description
Optical Sources	39	R/W	0 – 3	n/a	No	Sets the two optical sources to the states indicated by the data: 0 = both A & B sources off 1 = A on, B off 2 = A off, B on 3 = both A & B source on . This command is valid only when the operating mode is '2'.

6.4 Communications/Programming Example

Make sure you have the terminal setup correctly :
9600 baud 8 data bits and 1 stop bit.

Example 1:

To retrieve the Model Number send the following Command via a serial interface.

You must send the Start Transmission Character <EOT> followed by other command information (as Human Readable ASCII characters) followed by the End Of Command <ENQ> character.

Send: <EOT> EA16 <ENQ>

The unit will now respond with the Model Number:

Received: <STX> 16MR320 <ETX> <BCC>

The number 16 is the register address and MR320 is the requested information

Example 2:

Set the Full Scale Range for the voltage output to 500RPM so that at 500RPM the output will be 10V.
Use register 24 to set the value to 500.

Send: <EOT> EA <STX> 24500 <ETX> <BCC>

The unit will respond with:

Received: <ACK>

If there was a problem or the command was not received properly the unit will respond with <NACK>.
Always test the return for <ACK> or <NACK>.

Note: Blank spaces in above examples are for clarity only and must NOT be included in the actual commands.

6.5 Detailed Description of Each Function

This section describes the physical outputs from the encoder monitoring circuit.

6.5.1 Counter (Register 20)

Register Address: 20

This is an internal summing counter that keeps accurate track of the full number of quadrature cycles. For the 120-256 each 360 degree rotation produces 256 counts.

The counter is relative to a given starting position. The user may reset or preset the counter to any value within a full 24 bit range.

To request the Counter value:

<EOT> EA20 <ENQ>

To Preset the Encoder Counter to value 0:

<EOT> EA <STX> 20 <counter value> <ETX> <BCC>

Range is: $\pm 8,388,607$

The range is good for 32,768 revolutions in either direction when using a 256ppr encoder.

The (-) sign bit indicates that the encoder is turning Counter Clockwise CCW (looking at the encoder from the shaft end)

The encoder Counter is volatile and will be reset once electrical power is lost.

Example: Preset the Encoder Counter to value 0:

<EOT> EA <STX> 200 <ETX> <BCC>


Example: Preset the Encoder Counter to value 250:

<EOT> EA <STX> 20250 <ETX> <BCC>

6.5.2 Divider (Register 21)

Register Address: 21

The quadrature signal produced by the encoder can be divided down by a factor of 2 to 16,383- i.e., if you program a divide by 128, the unit will now produce 2 pulses per revolution when a 256ppr encoder is used.

 This function works reliably up to 52kHz encoder frequency (>3,000rpm for an MR324 encoder with 1024 slits). Consequently, users should not attempt to rely on this output if the encoder turns faster than 3000RPM (MR324).

The divided signal is externally available on connector J3.

To set the Divider to divide by 5 send:

<EOT> EA <STX> 215 <ETX> <BCC>

Range: User selectable. 0 and 2–16,383

☞ A special selection is the value 0. The value 0 turns this function OFF. This may be useful when the encoder is expected to operate at high speeds and the divided output is not required. When enabled, the divider function absorbs a significant amount of processor time and thus turning it off frees processor time for other functions such as RPM measurement and analog outputs.

☞ If the Divider function is not used, then it should be turned off by setting value to 0.

6.5.3 *RPM (Register 22)*

Register Address: 22

The MR320 continuously measures the elapsed time between encoder slits. This time period measurement allows accurate calculation of RPM.

The true RPM can be obtained at any time by requesting the value in register 22:

<EOT> EA22 <ENQ>

Output Format: The output is in RPM x 100 (12012 -> 120.12RPM)

Range: Lowest RPM is 0.33 and highest is 6,000

Accuracy: 1%

Resolution: 0.1 RPM regardless of scale

I/O: Serial Interface. See Section 6.2 for details.

6.5.4 *Voltage Mode (Register 23)*



Register Address: 23


The speed in RPM will be output as analog voltage to the voltage output.

The programming string for the Voltage Mode is as follows:

<EOT> EA <STX> 23 <mode> <ETX> <BCC>

Default: SPEED Mode 0

SPEED Modes	Description
0	<p>Output corresponds to actual RPM where CCW rotation is negative voltage.</p> <p>The voltage output range is 0V to +10V when the encoder rotates CW. Overrange extends from +10V up to +12V</p> <p>The voltage output range is 0V to -10V when the encoder rotates CCW. Overage extends from -10V to -12V.</p> <p style="text-align: center;">Voltage Speed Mode 0</p> 
1	<p>Output corresponds to the absolute value of the RPM, regardless of the direction.</p> <p>The output is always from 0V to +10V regardless of direction of rotation. Over range extends from +10V up to +12V</p> <p style="text-align: center;">Voltage Speed Mode 1</p> 

POSITION Modes	Description
2	<p>The output ranges from 0V to +10V (overrange from +10V to +12V) for CW motion with +10V corresponding to the Voltage Scale setting (Register 24).</p> <p>The output ranges from 0V to -10V (overrange from -10V to -12V) for CCW motion with -10V corresponding to the Voltage Scale setting (Register 24).</p> <p style="text-align: center;">Voltage Position Mode 2</p>  <p>The graph shows a linear relationship between Counter Value and Output Voltage. The x-axis is labeled 'COUNTER VALUE' with markers for -SCALE, 0, and +SCALE. The y-axis represents voltage with markers for +12V, +10V, 0V, -10V, and -12V. A solid line passes through (0, 0V). Dashed lines extend to +12V and -12V, labeled 'Overrange'. Arrows indicate 'CCW' (counter-clockwise) for negative counter values and 'CW' (clockwise) for positive counter values.</p>

The programming string for the Voltage Mode is as follows:

`<EOT> EA <STX> 23 <mode> <ETX> <BCC>`

Default: SPEED Mode 0

6.5.5 Voltage Scale (Register 24)

Register Address: 24

Default: 1000

The voltage scale can be set by the user to track SPEED or POSITION.

Example: With Voltage Mode (Register 23) set to 0, a Voltage Scale setting of **10** will provide a full scale +10V output for 10RPM (CW) or -10V output for 10RPM (CCW). Faster speeds will linearly extend from $\pm 10V$ until peaking at $\pm 12V$.

The programming for the Mode is as follows:

`<EOT> EA <STX> 24 <range data> <ETX> <BCC>`

Range	Description
0	The value 0 turns this function OFF. This may be useful when the encoder is expected to operate at high speeds and the voltage output is not required. Disabling this function leaves processor resources for other functions

	such as the quadrature divider. It is recommended to disable the output when it is not required.
10-10,000 (SPEED)	In a SPEED mode (Register 23), a Voltage Scale setting of X establishes $\pm 10V$ "full scale" value to correspond to X RPM.
1-8,388,607 (POSITION)	In a POSITION mode (Register 23), a Voltage Scale setting of X establishes $\pm 10V$ "full scale" output to correspond to X Counter value.

☞ A special selection is the value 0. The value 0 turns this function OFF. This may be useful when the encoder is expected to operate at high speeds and the voltage output is not required. Disabling this function leaves processor resources for other functions such as the quadrature divider. It is recommended to disable the output when it is not required.

6.5.6 Voltage Filter (Register 25)

Register Address: 25

A user configurable low pass filter exists to allow smoothing of the calculated RPM based on user constants. It is the filtered RPM that is output to the voltage DAC. The 3dB filter point is programmable from 500Hz (no filtering) down to 1Hz

$$A_f = \frac{(A_{f[t-1]} * n - 1) + A_m[t]}{n}$$

A_f : Filtered analog output value
 $A_{f[t-1]}$: Previous filtered analog output value
 n : filter constant in milliseconds
 A_m : new analog (unfiltered) value

The programming for the Mode is as follows:

<EOT> EA <STX> 25 <filter data> <ETX> <BCC>

Range: 0 to 256

Default: 32 (equivalent to ~5Hz filter frequency)

☞ The analog output is updated every 800 μ s thus when setting the filter value to n an approximate time constant of n ms can be expected. The MR320 measures the period between passing slits of the code wheel. When the encoder is turning slow so that the elapsed time between slits is large then 1ms then the low pass algorithm is changed

and the time constant becomes larger as the encoder turns slower. This adaptive filtering algorithm provides for a smooth output signal change.

☞ If no filtering is desired simply turn the filter OFF by setting it to value 1.

☞ When in position mode no filtering occurs regardless of the filter setting.

6.5.7 Current Mode (Register 26)

Register Address: 26


The scalable current output provides filtered RPM or POSITION analog output depending upon the chosen mode.

The programming for the Voltage Output Mode is as follows:



<EOT> EA <STX> 26 <mode> <ETX> <BCC>

Default: SPEED Mode 0

SPEED Modes	Description
0	<p>Bipolar output over 4mA to 12mA to 20mA where 12mA is equal to 0 RPM.</p> <p>CW rotation from 0RPM to (Current Scale) RPM corresponds to 12mA to 20mA. Overrange extends from 20mA to 24mA (maximum)</p> <p>CCW rotation from 0RPM to (Current Scale) RPM corresponds to 12mA to 4mA. Overrange extends from 4mA to 0mA (minimum).</p> <p style="text-align: center;">Current Speed Mode 0</p>
1	<p>Unipolar output range of 0-24mA where 0mA represents 0RPM, regardless of direction.</p>




POSITION Modes	Description
3	<p>Bipolar output over 0mA to 12mA to 20mA where 12mA is equal to the zero position/counter value.</p> <p>CW rotation from 0 counter value to Current Scale (Reg 27) setting corresponds to 12mA to 20mA. Overrange extends from 20mA to 24mA (maximum)</p> <p>CCW rotation from 0 counter value to negative Current Scale (Reg 27) setting corresponds to 12mA to 4mA. Overrange extends from 4mA to 0mA (minimum).</p> <p style="text-align: center;">Current Position Mode 3</p>
4	<p>Unipolar output range of 0-24mA representing the absolute value of the Counter. 0mA represents the zero position and 20mA corresponds to the Current Scale (Reg 27) setting (regardless of direction or sign). Overrange extends from 20 24mA (maximum).</p> <p style="text-align: center;">Current Position Mode 4</p>

5	<p>Unipolar output range of 4-24mA representing the absolute value of the Counter. 4mA represents the zero position and 20mA corresponds to the Current Scale (Reg 27) setting (regardless of direction or sign). Overage extends over 20-24mA range.</p> <p style="text-align: center;">Current Position Mode 5</p> 
6	<p>Window mode with Output range of 4-24mA. 4mA represents zero and negative position and 20mA corresponds to Current Scale (Reg 27). Overage extends over 20-24mA.</p> <p style="text-align: center;">Current Position Mode 6</p> 

In all cases there is an overrange capability of 4mA to 24mA.

Use the MODE command to select the desired output mode.



Current Output Cautions...

- Current outputs are inherently short circuit proof!
- The maximum burden resistance for the MR320 is 500 Ohm with a +24V power supply. At 24mA that represents a voltage drop of 12V.
- To minimize internal heat dissipation we recommend that the user inserts a 'burden resistance' to always assure at least 200 Ohm.

6.5.8 Current Scale (Register 27)


Register Address: 27

The programming for the Current Scale is as follows:

<EOT> EA <STX> 27 <range data> <ETX> <BCC>

Default: 1000 RPM/full range.

Range	Description
0	The value 0 turns this function OFF. This may be useful when the encoder is expected to operate at high speeds and the voltage output is not required. Disabling this function leaves processor resources for other functions such as the quadrature divider. It is recommended to disable the output when it is not required.
10-10,000 (SPEED)	In a SPEED mode (Register 26), a Current Scale setting of X establishes 20mA as “full scale” output corresponding to X RPM.
1-8,388,607 (POSITION)	In a POSITION mode (Register 26), a Current Scale setting of X establishes 20mA as the “full scale” output when the Counter value reaches X.

 A special selection is the value 0. The value 0 turns this function OFF. This may be useful when the encoder is expected to operate at high speeds and the current output is not required. Disabling this function leaves processor resources for other functions such as the quadrature divider. It is recommended to disable the output when it is not required.

6.5.9 Current Filter (Register 28)

Register Address: 28

A user configurable low pass filter exists to allow smoothing of the calculated RPM based on user constants. It is the filtered RPM that is output to the voltage DAC. The 3dB filter point is programmable from 500Hz (no filtering) down to 1Hz

$$A_f = \frac{(A_{f[t-1]} * n - 1) + A_{m[t]}}{n}$$


A_f : Filtered analog output value
 $A_{f[t-1]}$: Previous filtered analog output value
 n : filter constant in milliseconds
 A_m : new analog (unfiltered) value


The programming for the Filter Mode is as follows:


<EOT> EA <STX> 25 <filter data> <ETX> <BCC>

Where data can be from 1 to 255ms

Default: 32 (approx. 10Hz filter frequency)

 The output is updated every 1.024ms thus when setting the filter value to n an approximate time constant of n ms can be expected. The MR320 measures the period between passing slits of the code wheel. When the encoder is turning slow so that the elapsed time between slits is larger then 1ms then the low pass algorithm is changed and the time constant becomes larger as the encoder turns slower. This adaptive filtering algorithm provides for a smooth output signal change at low rpm.

 If no filtering is desired simply turn the filter OFF by setting it to value 1.

 When in position mode no filtering occurs regardless of the filter setting.

6.5.10 Counter Reset (Register 29)

Register Address: 29

The internal Position Counter may be reset by applying a +5V signal to the Counter RESET Input located on pin 11 of J1.

The programming for this function is :

<EOT> EA <STX> 29 <mode> <ETX> <BCC>

Check for a <ACK> that verifies command has been accepted

Default: Mode 0 (Edge trigger)

Modes	Description
0	The RESET Input is triggered by the rising edge (first transition) from 0V to 5V. The uncertainty of this input is maximum 800µs.
1	The RESET Input is conditioned for debouncing the input signal, such as a push button or relay contact. This setting allows a debounce period of approximately 60ms.

 When in Debounce mode, the signal must be at least 100ms in length to be effective.

6.5.11 Counter Multiplier (Register 2A)

Register Address: 2A

The internal position counter may be multiplied by two using only one half of a quadrature cycle to increment (decrement) the internal counter.

The programming is as follows:

<EOT> EA <STX> 2A <mode> <ETX> <BCC>

Check for a <ACK> that verifies command has been accepted

Default: Mode 0 (Multiply by 1)

Modes	Description
0	Normal counting (every cycle is one count).
1	This mode effectively doubles the position resolution of the internal Counter by incrementing after every half quadrature cycle. .

☞ When in mode 1 (x2 multiplication), be sure to set the slit count to double the number of slits the encoder has. This will ensure that the speed output will be correct.

☞ Due to the inner workings of the MR320 firmware, the Controller can only be set to x2 multiplication. It is not possible to do x4 or higher multiplication.

6.5.12 Encoder Direction (Register 2B)

Register Address: 2B

This parameter defines the encoder's rotational direction. When this parameter is set to "0" (default) all outputs follow the right-hand rule convention. When the encoder turns clockwise then the speed indication is positive and the position counter increments. Analog outputs follow accordingly: i.e. a positive speed is indicated by a positive voltage.

When this direction parameter is set to "1", then all directional outputs are reversed. This may become useful when an encoder cannot be installed to turn in the CW direction within a system definition for CW being positive speed or positive position.

The programming is as follows:

<EOT> EA <STX> 2B [0,1] <ETX> <BCC>

Check for a <ACK> that verifies command has been accepted.

Default : Mode 0 (CW direction)

Modes	Description
0	Analog outputs and digital read-out follow CW direction
1	Analog outputs and digital read-out are reversed from normal CW direction

☞ Quadrature outputs A&B and divider outputs A&B are not affected by this parameter setting. The user must assure proper wiring to achieve the desired direction of an externally connected device.


6.5.13 Hardware Reset Value (Register 2C)

Register Address: 2C

The internal Position Counter will be preset to this pre-programmed value whenever the Hardware Reset input goes from logic 0 to logic 1.

This function sets the encoder to an absolute position based on an external reference switch, the Hardware Reset. When the switch is activated then the absolute position is known. This parameter tells the encoder its absolute position when the hardware signal is generated.

Sometimes this function is also called “homing”



The programming is as follows:

<EOT> EA <STX> 2C <preset value> <ETX> <BCC>

Check for a <ACK> that verifies value has been accepted.

Default value: 0


6.5.14 Reset On Count/Homing (Register 2D)

Register Address: 2C

The internal Position Counter is automatically reset to 0 whenever its absolute value matches this pre-programmed value.

This is a useful command when it is desirable to use the encoder as an absolute position indicator over the course of one or multiple turns. For instance, the MR314 encoder may be used to output a voltage from 0V to 10V corresponding to the angular position from 0° to 359.9°. In this case the Auto Reset would be set to 1024 and the voltage scale value would be set to 1024. Voltage mode setting is 2. As the encoder turns the voltage increases from 0 to 10V and as the position counter reaches 1024 it automatically resets to 0 and the output voltage naturally follows to 0V – indicating 0° angular position. When the encoder turns CCW and passes through zero the counter resets to the maximum setting.

RESET ON COUNT Mode
(Example shown uses Current Position Mode 6
Where R=RESET Value)




The programming is as follows:

`<EOT> EA <STX> 2D <reset value> <ETX> <BCC>`

Check for a `<ACK>` that verifies value has been accepted.

Default value: 0 (deactivated)

 Comparison is based on the absolute value of the position counter. Reset to 0 occurs when the counter reaches either the positive or the negative preset value.

6.5.15 Saving Parameters in EEPROM (Register 13)

Register Address: 13

Parameters are not automatically saved to EEPROM. The user must issue a special command to commit the parameters to EEPROM. It is highly advisable to always initiate an EEPROM commit otherwise all the stored parameters will be lost when power is removed to the MR320 unit.


In addition to checksums, all parameters are stored twice internally and when retrieved both copies are compared and only restored when there is a match or when it is determined that there is one good copy of the parameter.

To store parameters into the EEPROM

The programming for the Saving parameters to EEPROM:

<EOT> EA <STX> 131 <ETX> <BCC>

Check for a <ACK> that verifies store has been completed.

 All parameters in EEPROM are always restored at power up. There is no special user interaction required to read parameters from the EEPROM.


7. Maintenance and Service

7.1 Encoder Will Not Produce Quadrature Signals

If you cannot get quadrature signal output on J1, then first make sure if the A and B LEDs on the front panel light up when the encoder shaft is rotated.

7.1.1 LED's Do Light Up

If the LEDs flicker ON and OFF, then it means the encoder quadrature signals are being generated but there still might be a short or disconnect with the wiring. Make sure that you are connected to Pin 1, or 2, or 4, or 5 on J1 of the MR320 box.



Current Limit of Push-Pull Outputs

Do not exceed 15mA current!

Although the outputs are short circuit protected – avoid prolonged shorts.

7.1.2 LED's Do NOT Light Up

If one or both LED's do not light up while rotating the encoder shaft, then not enough optical power is being received, cabling problems or the MR320 input amplifiers have not been calibrated properly.

- STEP 1. Calibrate the input amplifiers as described in Section 5.8 **First Time Start-Up** and Section 5.9 **Manual Gain Calibration (Manual Reset)**. If that did not solve the Problem and the LED's do not light up, then most likely the fiber optic connection to the encoder is bad.
- STEP 2. Check Fiber Optic Connections on both the encoder side and the controller side. Clean both connectors as described in Section 7.3 **Fiber Optic Connector Cleaning**.
- STEP 3. To check if the MR320 produces enough optical power, you must have a PC connected to the MR320 and ZAPPY™ software running and communicating with the MR320. Then disconnect the fiber optic cable from the MR320 and cover the connector interface to protect it from dust.
- STEP 4. With no optical connection to the MR320, select [DIAGNOSTICS] mode and all pertinent diagnostics information will be automatically retrieved from the MR320. The INPUT AMPLIFIER field displays the gain setting of the amplifier and the calculated received optical power for each channel. Press the RESET switch on the MR320 (located just below J1) to force the ZAPPY™ Gain Setting to 20 (maximum gain due to no reflected signal from encoder). Save Diagnostic Report to File and contact Micronor Technical Support.

7.2 Interface Problems

If communications cannot be established with a PC, proceed as follows:

- STEP 1.** Use the ZAPPY Software from Micronor and check if you can communicate using this software.
- STEP 2.** Make sure you use a correct interface cable - either USB or MR232-1 for RS232 communications.
- STEP 3.** If ZAPPY works but your software will not communicate then make sure you have set your serial interface to the proper baudrate, start/stop bit setup, etc. as described in Section 6.2.1. If ZAPPY™ does not establish communication, then we may suspect the interface cable, MR320 module or the computer serial interface.

7.2.1 Testing The USB Interface

The basic test for the USB cable or interface is to verify that the ZAPPY™, the PC and MR320 Controller are communicating with each other. As mentioned in Section 5.10, the first installation of ZAPPY™ on a particular PC may require 1 or 2 restarts as the appropriate Windows drivers are installed and the assigned COMx port becomes recognized by ZAPPY™.

- STEP 1.** First, connect USB cable and then start ZAPPY™ program. If ZAPPY cannot establish communications, then close ZAPPY™ and disconnect USB.

NOTE: There are several things that must happen in sequence so that is why it may take 2 or 3 program starts initially to get ZAPPY running and communicating to the MR320 Controller.

- FTDI driver must load
- Windows must install USB Serial Driver
- Windows assigns COMx Port to USB Serial Port
- ZAPPY finds the COMx Port and communications is complete

- STEP 2.** Repeat STEP 1 one or two more times. If you have further problems, please contact Micronor Technical Support.

7.2.2 Testing The Serial Cable

You may test the interface cable by converting it to a NULL Modem Cable.

- STEP 3.** Disconnect two wires from Pins 3 and 5 of J3 and twist the two ends together.
 - *Note the colors on the cable and pin location before removing otherwise you may reconnect them in the wrong position!*
 - *You must leave J3 connected to the MR320 box so that +5V power is supplied to the interface cable through PIN10.*

- STEP 4.** Now start up *WINDOWS Hyperterminal* on your PC. Type in any character and you should see that character being echoed back on the *Hyperterminal* screen. As shown in Figure 21, configure *Hyperterminal* with the proper communication settings - - Bits Per Second (9600), Data Bits (8), Parity (None), Stop bits (1) and Flow Control (None).
- STEP 5.** If the above is successful, then we know that the computer does send out and receive back signals properly through the cable. Verify again that the *Hyperterminal* communication settings (see Figure 21) have been set correctly for communicating with the MR320 because *Hyperterminal* can send and receive with any mix of settings.




Figure 21. Set-up Parameters for HYPERTERMINAL Program.

7.3 Fiber Optic Connector Cleaning

Mating clean fiber optic connector end faces is essential to proper performance of any fiber optic-based equipment. When fiber optic connectors are not properly handled, dirt, oil and other contaminants can accumulate on the ferrule body as well as the critical tip (or end face) as shown in Figure 22. Mating of dirty connectors will result in high loss as well as potentially damaging mated end faces.



Figure 22. Dirty and Clean Fiber Optic Connector Ferrule and Endface Views.

There are two basic methods – WET and DRY - for cleaning fiber optic connectors. The method depends on the degree and spread of surface contamination.

7.3.1 WET Cleaning Method

The **WET** method is the most fundamental and complete (but manual) way of cleaning optical surfaces and connector endfaces. As shown in Figure 23, the consumables required are reagent-grade isopropyl alcohol (IPA) and dry lintless non-abrasive wipes or swabs (e.g. Kimwipes, TexWipe Swabs, etc.). Pre-saturated wipes (e.g. Polywater Type FO, etc.) may also be used if they also have a low non-volatile residue content. In practice, saturate the wipe with IPA (or use an approved pre-wetted wipe) and then rigorously wipe the outer and end surfaces – then dry completely with a clean dry wipe.



Figure 23. WET Cleaning Method Requires IPA & Dry Wipes OR Pre-Wetted Wipes & Dry Wipes.

7.3.2 DRY Cleaning Method - Micronor MR321C DRY Cleaning Kit

The **DRY** method is meant for surface cleaning of the ferrule endfaces only. There are several products available (e.g. CLETOPS, ReelCleaner, etc.) and they all work satisfactory and typically clean the connectors quite well. When the DRY Method does not completely remove all contaminants, then use the WET Method.

Micronor offers the MR321C Duplex LC Fiber Optic Cleaning Kits as a simple and portable DRY cleaning solution for Duplex LC plugs and receptacles. One Cleaning Kit is supplied with each shipped lot of encoders and modules. Detailed cleaning instructions are supplied with each Cleaning Kit..



Figure 24. How To Use the MR321C Kit For Cleaning Duplex LC Optical Connectors and Interfaces.

Always visually inspect (with a fiber optic microscope) the optical plug or port (inside connector) after cleaning. If the terminated/polished end is still dirty or appears scratched, try the WET cleaning for better results. If visual inspection shows endface damage (scratches or pits in the core region), then have the connector end repolished or replaced.


7.4 Troubleshooting

If the encoder system does not function (but lights turn on) and does not pass the ZAPPY™ Performance Verification procedure (consult Section 5.11), then it is necessary to determine where the problem exists – Controller, Sensor or fiber optic link. Be sure that you have cleaned all optical connections per Section 7.3 and verified continuity of the fiber optic link per Section 7.5.

If unable to locate the source of the problem, then contact Micronor for additional troubleshooting and fault isolation assistance.

7.5 How To Verify Visual Continuity of Fiber Optic Cable Link

Figure 25 provides detailed flow chart showing how to verify continuity of the encoder optical link using a visual fault locator - a very basic, inexpensive and useful piece of fiber optic troubleshooting equipment.



Optical Warning

Never look directly at the output of an optical fiber with any source connected to it. Under some conditions, optical radiation can cause either temporary or permanent eye damage.

How To Verify Visual Continuity of Fiber Optic Encoder Link




Figure 25. How To Verify Optical Continuity With A Visual Fault Locator.

7.6 Blinking Error Codes

Besides indicating Power-On, the PWR LED on the MR320 module is also used to display various problem and/or error conditions. In normal operation, the PWR indicator will behave as follows:

- Continuously ON to indicate normal operation
- Will blink off for about 150ms each time a CALIBRATION cycle occurs.

An error condition is signified by the PWR LED blinking 1-5 times in a cycle repeated every 3.3 seconds. Note the number of blinks and contact Micronor for technical support.

The PWR LED blinking error codes are:

- One (1) blink indicates an EEPROM failure.
- Two (2) blinks indicate that the internal 2.5V supply is out of tolerance.
- Three (3) blinks indicate that the internal +5V supply is out of tolerance.
- Four (4) blinks indicate that the 12V supply is out of tolerance.
- Five (5) blinks indicate that the optical encoder signal cannot be CALIBRATED correctly.

In each of these instances, the encoder system continues to run, but may not operate properly. Use the ZAPPY diagnostic tool to determine what the exact cause may be.

For instance when the +12V (4 blinks) error is indicated than use the diagnostics to evaluate if the unit must be repaired or if it is still useable. The unit is useable as long as the internal voltage is +12V to +14.5V.

Five blinks indicate that the input optical amplifier is at maximum or minimum gain range. Minimum gain is indicated when the GAIN setting of either amplifier is at 127. As long as the input voltage of that particular channel is less than 2.4V the system may still be used. If the voltage exceeds the 2.4V the unit must be sent to the factory for recalibration of the optical transmitter. When the amplifier is at maximum gain setting of 1 than there is not enough optical power the reason for this is most likely:

- a.) high loss within the optical connections
- b.) defective encoder
- c.) defective optical transmitter unit (MR320)

For troubleshooting the connection please refer to section 5.5 within this instruction manual.


8. Reference Drawings

List of drawings which follow this page:

Micronor MR320: Controller Module Reference Drawing, 1 page
Micronor MR322: Optical Encoder Reference Drawing, 2 pages, Pigtail and ODVA versions
Micronor MR324: Optical Encoder Reference Drawing, 2 pages, Thru Bore and Pocket Hole versions
Micronor MR325: Optical Encoder Reference Drawing, 1 page
Micronor MR326: Optical Encoder Reference Drawing, 2 pages, Pigtail and ODVA versions
Micronor MR328: Optical Encoder Reference Drawing, 1 page
Micronor MR320-D06CXX: Duplex LC Fiber Optic Cable Assembly Drawing, 1 page

F9J 4G6 BG			
F9J *	89G7 F6HC B	85H9	5DDFC J98
7	58898 'I G6 7 C BB97 HC F)!(1%&	F; 6

8I D@L`@7 : 69F`C DH7
7 C BB97 HC F`DC FH'
5@K 5MG?99D`7 C J 9F98
5B8 : F99C : `8I GH
5B8 `8 F H




D-B`%C : `K 5; C
D@ ; `G`B 8 7 5H98
6MBC H7 < `B
@C K 9F`@: H<5B8
7 C FB9F

>%

>&

F9G9H6I HC B
5 7 7 9GG<C @9



I B #I A C I B H G`C B H C
G`5 B 8 5 F 8`") A A `8 B`F 5 @

>%K 5; C`DB.`+'`'!%&	
`f%&D-B`H9FA`B5@	
%`	5Ž
&`	5!
'`	B8
(`	6Ž
)`	6!
*`	B8
+	5`dd
,	6`dd
-`	B8
%\$`	ŽJg
%%`	fYgYh
%&`	g\Y`X




>&K 5; C`DB.`+'`'!%&\$	
`f%\$D-B`H9FA`B5@	
%`	8j 5Ž
&`	8j 5!
'`	B8
(`	8j 6Ž
)`	8j 6!
*`	B8
+	B8
,	±%\$J`Ci h
-`	B8
%\$`	(!&\$a 5`Ci h

>`K 5; C`DB.`+'`'!%\$*	
`f`D-B`H9FA`B5@	
%`	B8
&`	Ž)J`Ci h
'`	HŽ`→
(`	H!`→
)`	F7JŽ`←
*`	F7J!`←

BC H9G`I B @GG`C H 9FK`69`GD97 ÷ 98

I B @GG`C H 9FK`69`GD97 ÷ 98.		B5A 9	85H9	A`7FCBCF`B7` B9K 6I FMD5F?Z75 fI \$)E(-!\$%&)	
8A`9B`C`D`E`F`G`H`I`J`K`L`M`N`O`P`Q`R`S`T`U`V`W`X`Y`Z` 8F5K B		F`6C`M9F	-1%8%	7 C B H C`@`F Ž C D H 7 5 @ 9 B 7 C 8 9 F	
7<97798				GN9	
98: 5DDF*				8K ; ``"BC`"	
A:: 5DDF*				A F' &\$	
E`5`				F9J	
7CA A 98HG				7	
8H9FDF9H: 9CA 9HF7 HC`9F5B7B: D9F				G7 5@9.%%`K 9÷`<H`	
A 5H9F5@				G<99H% C :`%	
8C`B`CHG7 5@98F5K`B:					

REVISIONS			
REV.	DESCRIPTION	DATE	APPROVED
B	ADD SHEET 2	4-1-13	RGB



PART NUMBER ORDERING CODE

MR322 - D 06 C 1R5

RESOLUTION
A = 100
B = 128
C = 256
D = 360

PIGTAIL LENGTH IN METERS
(R = DECIMAL POINT)
1R5 = 1.5 METER

SHAFT SIZE IN MILLIMETERS
6 = 6MM SHAFT
($\phi 0.2358 \pm .0002$ [5.989 ± 0.010]
WITH 0.216 [5.50 FLAT])

CONNECTOR TYPE
C = DUPLEX LC



OTHER SHAFT OPTIONS ARE AVAILABLE

1. ALWAYS USE FLEXIBLE COUPLING WHEN MOUNTING SHAFT TO EXTERNAL EQUIPMENT.
2. WARNING: DO NOT DROP UNIT. DROPPING OR OTHER SEVERE SHOCK IMPACTS MAY DAMAGE UNIT.
3. WARNING: KEEP CONNECTOR COVERS IN PLACE DURING STORAGE, TO PROTECT FIBER OPTIC INTERFACES.

NOTES: UNLESS OTHERWISE SPECIFIED


PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF MICRONOR CORPORATION. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF MICRONOR CORPORATION IS PROHIBITED.

UNLESS OTHERWISE SPECIFIED:		NAME	DATE	MICRONOR INC. NEWBURY PARK, CA (805) 499-0114	
DIMENSIONS ARE IN INCHES [MM]		DRAWN	R BOYER	9-1-11	TITLE:
TOLERANCES:		CHECKED			OPTICAL ENCODER DUPLEX LC PIGTAIL
ANGULAR: $\pm .5^\circ$		ENG APPR.			
TWO PLACE DECIMAL $\pm .02$		MFG APPR.			
THREE PLACE DECIMAL $\pm .005$		Q.A.			SIZE DWG. NO. REV
FOUR PLACE DECIMAL $\pm .0010$		COMMENTS:			
INTERPRET GEOMETRIC TOLERANCING PER:					SCALE: 1:1 WEIGHT: SHEET 1 OF 2
MATERIAL					
FINISH					
DO NOT SCALE DRAWING					




OPTICAL ENCODER

MOUNTING PANEL
SYNCHRO CLAMP




[50.29]
Ø 1.980

SYNCHRO CLAMP
SUGGESTED MOUNTING PANEL
THRU-HOLE MOUNT WITH
SYNCHRO CLAMPS



MOUNTING PANEL
3X Ø0.169 THRU,
EQ SPCD AS SHOWN



SUGGESTED MOUNTING PANEL
COUNTER-BORED PANEL
WITH MOUNTING SCREWS

SECTION C-C

PART NUMBER ORDERING CODE

MR322 - D 06 D00

RESOLUTION

A = 100
B = 128
C = 256
D = 360

OPTICAL CONNECTOR
D00 = ODVA INDUSTRIAL LC
DUPLEX CONNECTOR

SHAFT SIZE IN MILLIMETERS

6 = 6MM SHAFT
(Ø 0.2358 ± 0.0002 [5.989 ± 0.010]
WITH 0.216 [5.50 FLAT])

OTHER SHAFT OPTIONS ARE AVAILABLE

3. WARNING: KEEP CONNECTOR COVERS IN PLACE
DURING STORAGE, TO PROTECT FIBER OPTIC
INTERFACES.

2. WARNING: DO NOT DROP UNIT. DROPPING
OR OTHER SEVERE SHOCK IMPACTS
MAY DAMAGE UNIT.


1. ALWAYS USE FLEXIBLE COUPLING WHEN
MOUNTING SHAFT TO EXTERNAL EQUIPMENT.

NOTES: UNLESS OTHERWISE SPECIFIED

REVISIONS			
REV.	DESCRIPTION	DATE	APPROVED
B	ADD SHEET 2	4-1-13	RGB

UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES TOLERANCES: ANGULAR: \pm 5° TWO PLACE DECIMAL \pm .02 THREE PLACE DECIMAL \pm .005 FOUR PLACE DECIMAL \pm .0010	DRAWN	R BOYER	4-1-13	MICRONOR INC. NEWBURY PARK, CA (805) 499-0114	
	CHECKED				
	ENG APPR.			TITLE: OPTICAL ENCODER ODVA LC	
	MFG APPR.				
INTERPRET GEOMETRIC TOLERANCING PER: MATERIAL FINISH DO NOT SCALE DRAWING	Q.A.			SIZE DWG. NO. REV C MR322-D00 B	
	COMMENTS:				
PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF MICRONOR CORPORATION. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF MICRONOR CORPORATION IS PROHIBITED.				SCALE: 1:1	WEIGHT: SHEET 2 OF 2

REVISIONS			
REV.	DESCRIPTION	DATE	APPROVED
C	REVISED	5-9-13	RGB



PART NUMBER ORDERING CODE

MR324- F 38 C 1R5

TEMPERATURE OPTION
(BLANK) = STANDARD, -40 °C TO +80 °C
E = EXTENDED, -60 °C TO +150 °C

RESOLUTION
F = 1024

PIGTAIL LENGTH IN METERS
(R = DECIMAL POINT)
1R5 = 1.5 METER

CONNECTOR TYPE
C = DUPLEX LC

HOLLOW SHAFT BORE IN MILLIMETERS
38 = 38MM HOLLOW SHAFT
THRU HOLE IP54
[Ø 38.026 ±0.013]
Ø 1.4971 ±0.0005

2. WARNING: KEEP CONNECTOR COVERS IN PLACE DURING STORAGE, TO PROTECT FIBER OPTIC INTERFACES.
1. WARNING: DO NOT DROP UNIT. DROPPING OR OTHER SEVERE SHOCK IMPACTS MAY DAMAGE UNIT.


NOTES: UNLESS OTHERWISE SPECIFIED

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF MICRONOR CORPORATION. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF MICRONOR CORPORATION IS PROHIBITED.

UNLESS OTHERWISE SPECIFIED:			
DIMENSIONS ARE IN INCHES	DRAWN	NAME	DATE
TOLERANCES:	CHECKED	R BOYER	9-1-11
ANGULAR: ± 5°	ENG APPR.		
TWO PLACE DECIMAL ±.02	MFG APPR.		
THREE PLACE DECIMAL ±.005			
FOUR PLACE DECIMAL ±.0010			
INTERPRET GEOMETRIC TOLERANCING PER:	Q.A.		
MATERIAL	COMMENTS:		
FINISH			
DO NOT SCALE DRAWING			

MICRONOR INC. NEWBURY PARK, CA (805) 499-0114			
TITLE: OPTICAL ENCODER DUPLEX LC			
SIZE C	DWG. NO. MR324	REV C	
SCALE: 1:2	WEIGHT:	SHEET 1 OF 2	

REVISIONS			
REV.	DESCRIPTION	DATE	APPROVED
C	REVISED	5-9-13	RGB



DUPLEX LC CONNECTOR
ON PIGTAIL, 1.5 METER LG

PART NUMBER ORDERING CODE

MR324- F 38P C 1R5

TEMPERATURE OPTION
(BLANK) = STANDARD, -40 °C TO +80 °C
E = EXTENDED, -60 °C TO +150 °C

RESOLUTION
F = 1024

PIGTAIL LENGTH IN METERS
(R = DECIMAL POINT)
1R5 = 1.5 METER

CONNECTOR TYPE
C = DUPLEX LC

SHAFT POCKET BORE IN MILLIMETERS
38P = 38MM CLOSED END
SHAFT POCKET IP66
[Ø 38.026 ±0.013]
Ø 1.4971 ±0.0005

2. WARNING: KEEP CONNECTOR COVERS IN PLACE DURING STORAGE, TO PROTECT FIBER OPTIC INTERFACES.
1. WARNING: DO NOT DROP UNIT. DROPPING OR OTHER SEVERE SHOCK IMPACTS MAY DAMAGE UNIT.

NOTES: UNLESS OTHERWISE SPECIFIED


PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF MICRONOR CORPORATION. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF MICRONOR CORPORATION IS PROHIBITED.

UNLESS OTHERWISE SPECIFIED:	
DIMENSIONS ARE IN INCHES	
TOLERANCES:	
ANGULAR: ± 5°	
TWO PLACE DECIMAL ±.02	
THREE PLACE DECIMAL ±.005	
FOUR PLACE DECIMAL ±.0010	
INTERPRET GEOMETRIC TOLERANCING PER:	
MATERIAL	
FINISH	
DO NOT SCALE DRAWING	

DRAWN	NAME	DATE
CHECKED	R BOYER	4-5-13
ENG APPR.		
MFG APPR.		
Q.A.		
COMMENTS:		

MICRONOR INC. NEWBURY PARK, CA (805) 499-0114	
TITLE: OPTICAL ENCODER POCKET HOLE VERSION	
SIZE C	DWG. NO. MR324
SCALE: 1:2	WEIGHT:
SHEET 2 OF 2	

REVISIONS			
REV.	DESCRIPTION	DATE	APPROVED
A	NEW RELEASE	6-28-12	RGB



PART NUMBER ORDERING CODE

MR325 - F 12 D00

RESOLUTION (PPR)
F = 1024

SHAFT SIZE IN MILLIMETERS
12 = 12 MM SHAFT

TEMPERATURE RANGE
(BLANK) = STANDARD
(-40 °C TO +80 °C)

OPTICAL CONNECTOR
D00 = INDUSTRIAL
LC DUPLEX
CONNECTOR



- 3 WARNING: KEEP CONNECTOR COVERS IN PLACE DURING STORAGE, TO PROTECT FIBER OPTIC INTERFACES.
- 2 WARNING: DO NOT DROP UNIT. DROPPING OR OTHER SEVERE SHOCK IMPACTS MAY DAMAGE UNIT.
- 1 ALWAYS USE FLEXIBLE COUPLING WHEN MOUNTING SHAFT TO EXTERNAL EQUIPMENT.

NOTES: UNLESS OTHERWISE SPECIFIED

<div>PROPRIETARY AND CONFIDENTIAL</div> <div>THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF MICRONOR CORPORATION. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF MICRONOR CORPORATION IS PROHIBITED.</div>	UNLESS OTHERWISE SPECIFIED:		NAME	DATE	MICRONOR INC. NEWBURY PARK, CA (805) 499-0114				
	DIMENSIONS ARE IN INCHES TOLERANCES: ANGULAR: $\pm 5^\circ$ TWO PLACE DECIMAL $\pm .02$ THREE PLACE DECIMAL $\pm .005$ FOUR PLACE DECIMAL $\pm .0010$		DRAWN	R BOYER			6-28-12		
	INTERPRET GEOMETRIC TOLERANCING PER: MATERIAL		CHECKED			TITLE: INCREMENTAL ENCODER			
			ENG APPR.						
			MFG APPR.						
			Q.A.						
	FINISH		COMMENTS:				SIZE	DWG. NO.	REV
	DO NOT SCALE DRAWING					C	MR325-F12D00	A	
						SCALE: 1:1		WEIGHT:	SHEET 1 OF 1

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF
MICRONOR CORPORATION. ANY
REPRODUCTION IN PART OR AS A WHOLE
WITHOUT THE WRITTEN PERMISSION OF
MICRONOR CORPORATION IS
PROHIBITED.

REVISIONS			
REV.	DESCRIPTION	DATE	APPROVED
B	REVISED	6-28-12	RGB



RESOLUTION
C = 256

SHAFT SIZE IN MILLIMETERS
12 = 12MM SHAFT
OTHER SHAFT OPTIONS
ARE AVAILABLE


CONNECTOR TYPE
C = DUPLEX LC

PIGTAIL LENGTH IN METERS
(R = DECIMAL POINT)
1R5 = 1.5 METER

TEMPERATURE RANGE
(BLANK) = STANDARD
(-40°C TO +80°C)

- 3 WARNING: KEEP CONNECTOR COVERS IN PLACE DURING STORAGE, TO PROTECT FIBER OPTIC INTERFACES.
- 2 WARNING: DO NOT DROP UNIT. DROPPING OR OTHER SEVERE SHOCK IMPACTS MAY DAMAGE UNIT.
- 1 ALWAYS USE FLEXIBLE COUPLING WHEN MOUNTING SHAFT TO EXTERNAL EQUIPMENT.



NOTES: UNLESS OTHERWISE SPECIFIED



UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES TOLERANCES: ANGULAR: ± 5° TWO PLACE DECIMAL ± .02 THREE PLACE DECIMAL ± .005 FOUR PLACE DECIMAL ± .0010	DRAWN	NAME	DATE	MICRONOR INC. NEWBURY PARK, CA (805) 499-0114	
	CHECKED				
	ENG APPR.			TITLE: SENSOR, 90MM, DUPLEX LC	
	MFG APPR.				
INTERPRET GEOMETRIC TOLERANCING PER: MATERIAL FINISH	Q.A.			SIZE DWG. NO. REV C MR326-CXXCXXX B	
	SEE NOTES				
	DO NOT SCALE DRAWING				
COMMENTS:				SCALE: 1:1	WEIGHT: SHEET 1 OF 1

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF
MICRONOR CORPORATION. ANY
REPRODUCTION IN PART OR AS A WHOLE
WITHOUT THE WRITTEN PERMISSION OF
MICRONOR CORPORATION IS
PROHIBITED.

REVISIONS			
REV.	DESCRIPTION	DATE	APPROVED
A	NEW RELEASE	6-28-12	RGB



PART NUMBER ORDERING CODE
MR326 - C 12 D00

RESOLUTION
C = 256


SHAFT SIZE IN MILLIMETERS
12 = 12MM SHAFT

OPTICAL CONNECTOR
D00 = INDUSTRIAL
LC DUPLEX
CONNECTOR

TEMPERATURE RANGE
(BLANK) = STANDARD
(-40 °C TO +80 °C)


- 1 ALWAYS USE FLEXIBLE COUPLING WHEN MOUNTING SHAFT TO EXTERNAL EQUIPMENT.
- 2 WARNING: DO NOT DROP UNIT. DROPPING OR OTHER SEVERE SHOCK IMPACTS MAY DAMAGE UNIT.
- 3 WARNING: KEEP CONNECTOR COVERS IN PLACE DURING STORAGE, TO PROTECT FIBER OPTIC INTERFACES.

NOTES: UNLESS OTHERWISE SPECIFIED



UNLESS OTHERWISE SPECIFIED:		NAME	DATE	MICRONOR INC.	
DIMENSIONS ARE IN INCHES		DRAWN	R BOYER	6-28-12	NEWBURY PARK, CA (805) 499-0114
TOLERANCES:		CHECKED			TITLE:
ANGULAR: ± 5°		ENG APPR.			SENSOR, INDUSTRIAL,
TWO PLACE DECIMAL ± .02		MFG APPR.			90MM, LC DUPLEX
THREE PLACE DECIMAL ± .005		Q.A.			SIZE DWG. NO.
FOUR PLACE DECIMAL ± .0010		COMMENTS:			C MR326-C12D00
INTERPRET GEOMETRIC TOLERANCING PER:					REV
MATERIAL					A
FINISH					
DO NOT SCALE DRAWING					SCALE: 1:1 WEIGHT: SHEET 1 OF 1

F9J 4G6 BG			
F9J "	8 9G7 F 6HC B	85H	5DDFC J 98
5	B 9K F 9@95 G9	-!%8%	F; 6



D5FHBI A 69F 'C F 8 9F B; 7 C 8 9
A F' &\$! '8\$* '7 LLL

7 5 6@9 HMD9
8\$* ! 8I D@L '@ ž
.....* &") #%(&) # \$\$\$\$
.....DI F '>5 7 ? 9H

7 5 6@9 @B; Hk 'fIB 'A 9H9FG
.....fF '1 '8 97 A 5@DC B H
..\$\$ \$ 1 %\$ A 9H9FG
..\$\$\$ 1 %\$\$\$ A 9H9FG
..%F) '1 %) 'A 9H9FG

' ""C DH7 5 @D9F: C FA 5B 7 9
.....@. " Q \$"&) X 6'D9F 'H5!())!%+ %5 žA 9H<C 8 '8' "
.....F@ "2" \$X 6'D9F 'H5!())! , "

&"'K 5FB B; . 8C 'BC H8FC D'7 5 6@9 '5 GGM' '8FC DD B;
.....C F 'C H<9F 'G9J 9F 9'G<C 7 ? 'A D5 7 HG
.....A 5M85A 5; 9 7 5 6@9 '5 GGM

%"'K 5FB B; . ? 99D'7 C BB 97 HC F '7 C J 9FG B 'D@5 7 9
.....8I F B; 'GHC F 5; 9 žHC 'DFC H97 H: 69F 'C DH7
.....B H9F: 5 7 9G"

BC H9G 'I B @9GG' C Hk 9FK 69GD97 ÷ 98

1 B @9G C H<9FK 69GD97 ÷ 98.		B5A 9	85H	A 7FCBCF 'B7 "	
8 A 9BGC B G5F9 'B 'B7 <9G HC @9F5B7 9G 5B: 1 6F. ±") * HK C D@5 7 9 8 97 A 5@ " ±"\$& H: F 99 D@5 7 9 8 97 A 5@ ±"\$& : C I F D@5 7 9 8 97 A 5@ ±"\$&\$		8F5K B	F 6C M9F	-!%8%	B 9K 6I FMD5F?ž7 5 f) \$) E(- -!\$%8(
B H9F D F 9H: 9C A 9H F 7 HC @9F5B7 8: D9F		7 < 97 7 98			H 89.
A 5H9F 5@		98: 5DDF*			8I D@L '@ 7 5 6@9 '5 GG9A 6@M
7 C A A 98HG		A:: 5DDF*			
E "5"					
D F C D F @ 6 F M 5 8 8 7 C B: 8 9 B 5 @ H: 9 B: C F A 5 H C B 7 C B H 5 B 9 8: B H: 6 8 F 5 K B: " 6 H 9 G C @ 9 D F C D 9 F H M C: A 7 F C B C F 7 C F D C F 5 H C B " 5 B M F 9 0 F C 8 I 7 H C B B D 5 F H C F 5 G 5 K < C @ K H: C I H H: 9 K F H 8 B D 9 F A G G C B C: A 7 F C B C F 7 C F D C F 5 H C B G D F C < 4 H 8					G M 9
8 C B C H G 7 5 @ 8 F 5 K B:					8 K ; ""BC "
					A F' &\$! 8\$* 7 LLL
					F 9J
					7
					5
					G 7 5 @. & %
					K 9 ÷ < H'
					G< 99H% C: %